Seconds	Miles	Seconds	Miles
per	per	per	per
Mile	Hour	Mile	Hour
45	80	63	57.1
46	78.3	64	56.3
47	76.6	65	55.4
48	75	66	54.5
49	73.5	67	53.7
50	72	68	52.9
51	70.6	69	52.2
52	69.2	70	51.4
53	67.9	75	48
54	66.7	80	45
55	65.5	85	42.4
56	64.3	90	40
57	63.2	100	36
58	62.1	120	30
59	61	144	25
60	60	180	20
61	59	240	15
62	58.1	360	10

# WATCH INSPECTORS

	N. 221 Washington St., Harold J. March
Spokane	
Malden	Pacific Watch Co.
Pine City	C. N. Harthill
Othello	Pacific Watch Co.
	James P. Nelson
Ellensburg	3041/2 No. Pearl St., Chas. E. Dickson
Cle Elum	Dean R. Ireland
Seattle	414 Pike St., Weisfield & Goldberg, Inc.
Seattle	425 Pike St., Corner 5th Ave., H. Raphael
Seattle	4551 Calif. Ave., Reibman Jeweler
	First Ave. So. & Lander, c/o Sears,
T	Roebuck & Co., Lonnie Wilcox 1105 Broadway, A. A. Mierow
	1016 So. 11th St., A. C. Paulson
	3815 So. Yakima Ave., Denzer's Jewelry
	2934 Colby Ave., O. P. Nelson
	1639 Cole St., Miller's Jewelry
	Wright Jewelers
	Fred Wetzel
Raymond	223 Duryea St., Antilla & Kolcz Jewelers
South Bend	Halver Holte
	Milton E. Terry
Port Angeles	Lewie B. Filion
Port Townsend	840 Water St., Walter S. Wisniewski
Longview	310 Commerce Ave., Friedlander & Sons, Inc.



# CHICAGO, MILWAUKEE, ST. PAUL AND PACIFIC RAILROAD CO.

# COAST DIVISION

# TABLE No. 3

Taking effect at 12:01 A.M.
Pacific Standard Time

SUNDAY, JUNE 7, 1959

For the government and information of employees only

A. W. HERVIN
Assistant Superintendent

W. F. BANNON
Assistant Superintendent

N. H. McKEGNEY
Superintendent

Q. W. TORPIN
Superintendent of Transportation

V. P. SOHN
General Superintendent of Transportation

R. G. SCOTT Assistant to General Manager L. V. ANDERSON General Manager

2		W	/EST\	VAR	D		FIRST SUBDI	VISIC	N	EASTWARD			
	SECOND CLASS	FIRST CLASS		Time Table		13 117 250 18	FIRST CLASS	SECOND CLASS					
	263	15	Capacity	y in cars		from	No. 3	Distance from Othello	See Rule 6-A	Office Hours Also See Page 14 for Other Assigned Hours	16	264	
	Time Freight	Passenger		24	rapl	nce	JUNE 7, 1959	lo de	8 2	Assigned Hours	Passenger	Time Freight	
	Daily	Daily	Sidings	Other tracks	Telegraph calls	Distance Malden	STATIONS	Distr			Daily	Daily	
	L 8.25			Yard	M	0.0	MALDEN	103.4	BHKPRWXY	12.01 AM to 5.00 PM	2004 H 127 (28	A 11.01PM	
. 1000 1 01 0	8.31			27		3.6	PINE CITY	99.8	P	No Office		10.43	
	8.34		58			5.6	KENOVA	97.8	P	No Office		10.37	
	8.46		63			11.3	ROCK LAKE	92.1	P	No Office		10.27	
	8.56	a	112			17.0	5.7 LAVISTA	86.4	P	No Office		10.12	
	8.59		26	9		19.2	EWAN 10.4	84.2	PW	No Office		10.08	
	9.14	100 A NEWS POLYMON	110	31		29.6	REVERE	73.8	P	No Office		9.45	
	9.20		61			33.7	PAXTON	69.7	. Р	No Office	51000 N - 1 N	9.35	
		L 12.01AM			SN		SPOKANE		BKOPRVWZ	Via U. P. R. R.	A 10.55PM		
	9.50	L 1.16AM	87	41	RA	44.0	MARENGO	59.4	JPRVWXY	Continuous	A 9.30PM	9.05	
	10.02	1.23	59			49.9	HILLCREST	53.5	P	No Office	9.20	8.45	
	10.06	1.27	107	28		53.5	RALSTON	49.9	P	No Office	9.16	8.35	
			-	25		58.5	PIZARRO	44.9	P	No Office			
	10.17	1.37	61			63.3	VASSAR	40.1	P	No Office	9.06	8.15	
7	10.23	1.42	158	33	NE	68.0	4.7 ————————————————————————————————————	35.4	P	7.00 AM to 4.00 PM Exc. Sat. & Sun.	9.01	8.05	
Ш	10.32	1.50	63			78.0	SERVIA	27.4	P	No Office	8.53	7.50	
	10.38	1.55	117	29		80.9	ROXBORO	22.5	P	No Office	8.48	7.40	
	10.50	2.04	175	50	wx	90.6	9.7 WARDEN 	12.8	JPY	8.00 AM to 5.00 PM Exc. Sat. & Sun.	8.39	7.25	
	11.02	2.12	60			99.4	NOVARA	4.0	P	No Office	8.31	7.10	
	A 11.15AM	As 2.26M		Yard	so	103.4	OTHELLO	0.0	BHKOPRTWX	Continuous	L 8.25m	L 7.01PM	

#### EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

Between Malden and Marengo passenger trains must not exceed a maximum speed of 55 M. P. H., other trains 40 M. P. H. Between Marengo and Othello passenger trains 79 M. P. H., other trains 55 M. P. H.

This time-table confers no authority between Marengo and Spokane. Union Pacific R. R. time table and rules govern.

Automatic Block System is in use between Marengo and Othello. At Warden, at east end of siding, the normal position of the west wye switch is for movement from the siding to the west leg of the wye. The time of eastward trains departing from Othello applies at the east crossover, located 1275 feet east of depot. Under train order meets or waits, westward trains entering Othello will take siding at this crossover unless otherwise designated in the orders.

INDUSTRIAL '	TRACKS N	OT SHOV	VN AS STA	ATIONS
Name	Cap. In	Miles	Direction	Station
arlmar	б	8.0	East	Marengo
ast Lind lole Track	162	0.1	East West	Lind Lind

10)		WES	TW	ARE	)		SECOND SUBDI	VISI	ON	EASTW	ARD	30 a s n	3	
SECOND CLASS	FIRST	CLASS	Capa	city in			Time Table	40		Office Have	FIRST	CLASS	SECOND CLASS	
263		15		ı	Telegraph calls	Distance from Othello	9	No. 3  JUNE 7, 1959  STATIONS  Office Hours Also See Page 14 for Other Assigned Hours Passenger Daily		See Rule Also See Page		264		
Time Freight		Passenger	Sid- ings	Other tracks	ектар	tande	JUNE 7, 1959	Elun	U.A.	Assigned Hours	Passenger		Time Freight	
Daily		Daily	шдь	\$1.8CKB	T <sub>e</sub>	100	STATIONS	_ වීවී			Daily		Daily	
L 12.15PM		L 2.36A		Yard	80	0.0	OTHELLO	98.9	BHKOPR TWX	Continuous	As 8.20M		A 5.00P	
12.31		2.49	113	11		9.2	TAUNTON 5.8	89.7	P	No Office	8.05		4.05	
12.41		2.55	60	18		15.0	CORFU	83.9	P	No Office	7.56		3.45	
12.55		3.06	111	10		24.7	SMYRNA 13.1	74.2	P	No Office	7.45		3.20	
1.20	F = 5 = 5	3.22	113	Yard	вч	37.8	BEVERLY	61.1	вкрху	12.01 AM to 4.00 PM Except Sat. & Sun	7.28	K K**	2.40	
				180		38.8	BEVERLY JCT.	60.1	JPX	No Office				
264 1.50		3.36	113			44.0	DORIS	54.9	P	No Office	7.16		263 1 · 50	
2.10		3.47	60	5		49.6	RYE	49.3	P	No Office	7.05	2	1.30	
2.45		4.01	103	20		56.6	BOYLSTON 8.3	42.3	P	No Office	6.50		1.00	
3.15	V . 1			17		64.9	EAST KITTITAS	34.0	P	No Office			12.25	
3.25	c es	4.21	113	85	KY	67.2	KITTITAS	31.7	KPWXY	8.00 AM to 5.00 PM Except Sat. & Sun.	6.34	8= 2 =	12.208	
	WORN PASSESSES IN		110000	14		70.1	REGAL	28.8		No Office	SH SH			
3.35		4.31	91	48	NB	73.6	ELLENSBURG	25.3	P	8.00 AM to 5.00 PM Except Sat. & Sun.	6.27	A 9 58	11.59	
3.45		4.39	60	27		80.5	THORP	18.4	P	No Office	6.16	etalete i radar u. Soo	11.50	
4.00	E E	4.52	109	8		88.9	HORLICK	10.0	P	No Office	6.05	6	11.30	
A 4.25P	W	As 5.08M		Yard	CM	98.9	CLE ELUM	0.0	BKPRWX	Continuous	L 5.53PM	5 12 1 58	L 11.054	

Passenger trains must not exceed 79 MPH. Other trains 55 MPH.

EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

Automatic Block System is in use between Othello and Cle Elum.

Rule 83(B) does not apply at Beverly Jct.

Mountain grade extends from Beverly Jct. to East switch at Kittitas.

At Beverly Jct. the normal position of junction switch is for the Second Subdivision.

4		WES'	TW	ARD	11	=	THIRD SUBDIVI	SIO	N	EASTW	EASTWARD				
SECOND CLASS	FIRST	CLASS	Capac				Time Table			2 s un	FIRST	CLASS	SECOND CLASS		
263	75.	15	Cı	urs	ph calls	Distance from Cle Elum	No. 3	Distance from Seattle	See Rule 6-A	Office Hours Also See Page 14 for Other Assigned Hours	16	*	264		
Time Freight		Passenger	Sid-	Other	Telegraph	stanc e Elu	JUNE 7, 1959	stanc attle	e	Assigned fronts	Passenger		Time Freight		
Daily		Daily	ings	tracks	Te	ÖÖ	STATIONS	S Di			Daily		Daily		
L 4.40PM		L 5.084		Yard	CM	0.0	CLE ELUM	89.9	BKPRWX	Continuous	As 5.53PM		A 10.35M		
5.08	=	5.20	106	34	55	11.6	EASTON 8.5	78.3	PVY	No Office	5.38		10.00		
16 5.26	- 1	5.30	70	15		20.1	WHITTIER  8.9	69.8	P	No Office	263 <b>5</b> .26		9.40		
5.45	= 0 11	5.41	98	106		29.0	HYAK	60.9	PX	No Office	5.15		9.20		
5.55		5.46	37			31.6	ROCKDALE	58.3	PWX	No Office	5.09		9.05		
6.10		5.58	69			36.7	5.1———BANDERA	53.2	P	No Office	4.59	NO WISHAGO ENGINEERS OF	8.50		
6.26		6.07	56	12		42.0	GARCIA	47.9	P	No Office	4.48		8.35		
6.41		6.17	101	21		46.5	RAGNAR	43.4	P	No Office	4.39	551	8.20		
6.55	Asa ol	6.26	135	895	MY	50.8	CEDAR FALLS	39.1	BJKOPW XYZ	2.00 AM to 11.59 PM Except Sat., Sun. & Mon.	4.31		7.55		
7.04		6.32				54.8	BAGLEY JCT.	35.1	JP	No Office	4.26		6.35		
7.06		264 6.33	59			55.6	BARNESTON	34.3	P	No Office	4.25		15 6.33		
7.14		6.38	115			59.5	TRUDE	30.4	P	No Office	4.19		6.20		
A 7.30PM		A 6.49M	79	14	МΫ	67.8	MAPLE VALLEY	22.1	JPRVX	Continuous	L 4.08M		L 5.55A		
7.55	= > p	7.06			RN	78.1	(N. P. Crossing) RENTON 2.4	11.8	PV	E 6 8	3.53		5.25		
8.01	6.00	7.10		Yard	ві	80.5	BLACK RIVER (U. P. Crossing)	9.4	IJPRVXY	e Se e II	3.46	2 2	5.15		
8.20			111	336		84.8	VAN ASSELT	5.1	P	Via. P. C. R. R.			4.45		
Aure Francisco	# # + #	7.26	= ,:	à		86.5	ARGO (U. P. Crossing) (N. P. Crossing)	3.4	IP	a E sa x	3.38	9 52 5 22	° a dia		
	v serven 3					88.2	SPOKANE STREET TOWER	0.7		Via. P. C. R. R.					
A 9.30 PM						88.9	STACY STREET YARD	0.0	BOPTVXZ				L 4.00 AM		
70 3		As 7.45 AM		Yard	OW	89.9	SEATTLE	0.0	P	Vis. U. P. R. R.	L 3.30 PM				

Passenger trains must not exceed a maximum speed of 70 MPH. Other trains 50 MPH.

# EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

# INDUSTRIAL TRACKS NOT SHOWN AS STATIONS

Name	Miles	Direction	1	Station
Landsburg	2.6	West	Trude	

This time-table confers no authority between Maple Valley and Seattle. Between Maple Valley and Spokane St. tower, Pacific Coast time-table and rules govern. Between Argo and Union Passenger Station Seattle, Union Pacific R. R. time-table and rules govern.

Rule 83(B) does not apply at Bagley Jct.

Automatic Block System is in use between Cle Elum and Maple Valley.

Mountain grade extends from Cedar Falls depot to one mile west of Hyak.

Headlight and marker lamps must be lighted while passing through Snoqualmie Tunnel No. 50 between Hyak and Rockdale.

Passenger trains must not exceed a maximum speed of 79 MPH. Other trains 55 MPH.

#### EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

INDUSTRIAL 1	INDUSTRIAL TRACKS NOT SHOWN AS STATIONS											
Name	Miles	Direction	Station									
Concora	08	West	Black River Puvallup									

37.6

West End'Double Track

TIDE FLATS YARD

Yard

This time-table confers no authority between Black River and Seattle. Between Black River and Spokane St. tower Pacific Coast R. R. time-table and rules govern. Between Argo and Union Passenger Station Seattle, Union Pacific R. R. time-table and rules govern.

Automatic Block System is in use between Black River and Tacoma Ict.

No. 15 will stop on signal at Auburn to let off revenue passengers from Spokane or points beyond.

No. 51 will stop on signal Kent. Auburn and Sumner to receive revenue passengers for Vancouver, Wash., and beyond.

Double track is in use between Tacoma Jct. and Tide Flats Yard. Trains and engines using these tracks must use the right hand track as prescribed by Rule D-151. Crossover movements and movements against the current traffic between Tacoma Jct. and Depot Switch must be properly protected and all trains and engines must move at restricted speed. Maximum speed must not exceed 15 MPH.

5.00PM

A 9.30PM

Single track is in use between Depot Switch and Tacoma. Normal position for the switch at Depot Switch is for movement to Tide Flats yard.

At Tacoma Jct. the normal position of junction switch is for the Eleventh Subdivision.

The following tracks are wired: 6, 7, 8, 12 and east end of track 13, Seattle Union Station, and first three cross-over tracks east of station: Northern Pacific Railway Co. interchange track, Argo, and tracks 1 and 8 Van Asselt.

At Auburn, an auxiliary siding with a capacity of 58 cars is located west of the depot. Rule S-5 applies at the siding located east of the depot.

See additional Special Instructions for Fourth Subdivision on Page 6.

Time Table	÷		¥		FIRST CLASS						SECOND CLASS					
No. 3	Ber on	1	Office Hours		54	52	ai ei	16	11		84	20	54	94		82
JUNE 7, 1959 STATIONS	Distance from Tacoma	See Rule 6-A	Also See Page 14 for Other Assigned Hours		P. R. R. assenger 401	U. P. R. R. Passenger 457		Passenger	<	U. Tir	. P. R. R. me Freight 691	Time 1	Freight	Way Freight	U. Tir	P. R. R no Freigh 681
SIRIIONS	ig E	No -			Daily	Daily	Daily				Daily	Da	aily	Daily Except Sunday		Daily
SEATTLE	37.6	P	Via U. P. R. R.	1000			As	3.15PM							_	
STACY ST, YARD	36.6	BOPT VXZ												A 12.50PM		N
SPOKANE ST. TOWER	35.9		Via P. C. R. R.											12.45		
ARGO (U. P. Crossing) (N. P. Crossing)	34.2	IP	Via P. C. R. R.			2 Å		3.03					-	12.35		
VAN ASSELT	32.5	P			•									12.30		
BLACK RIVER (N. P. Crossing)	28.2	IJPRVXY	Continuous	A	6.00AM	∆ 12.42PW	A	2.55PM	3	A	4.10AM	A 4	.30AN	A 12.20PM	A	4.40
KENT 5.0-	21.3	PX	8.00 AM to 5.00 PM Except Sat. & Sun.	8	5.50	12.34	ā	93 2.46			3.56	4	.19	12.05M		4.27
AUBURN	16.3	PX	7.45 AM to 5.00 PM Except Sat. & Sun.	5	5.40	12.28	f	2.40	11		3.45	4	.09	11.30		4.17
BENROY	11.7	P	No Office		5.30	12.23					3.35	3	.59	11.05		4.07
SUMNER	9.2	PVX	7.00 AM to 11.00 PM Except Sat. & Sun.	5	5.27	12.20		2.32	i i		3.28	3	.54	11.00		93 <b>4</b> .01
PUYALLUP	7.5	P	No Office		5.17	12.17	70	2.29			3.23	3	.50	10.10		3.57
TACOMA JCT.  East End Double Truck	2.0	JKPRVX	Continuous	ь	5.11AM	L 12.11PM		2.23		L	3.10M	3	.40	9.55	L	3.45
(G.N., U.P. & N. P. Crossing) DEPOT SWITCH	0.5	MPX	No Office			an_ = 0		2.17						n 9		
TACOMA	0.0	BPX	No Office			. 1181	L	2.15PM	e		= 11 ,8			A 25		
West End Double Track TIDE FLATS YARD	0.0	BKOPRT VWXYZ	No Office			12						г з	.30AM	L 9.45M		

Passenger trains must not exceed a maximum speed of 79 MPH. Other trains 55 MPH.

#### EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

# UNION PACIFIC RR—BLACK RIVER WHISTLE SIGNALS:

# NORTHERN PACIFIC RR - BLACK RIVER

Trains approaching interlocking, desiring to use main track to Tacoma or Seattle will give one long sound of the whistle. Trains desiring to use wye, will give four long sounds of the whistle.

No. 16 will stop on signal at Auburn for revenue passengers to Spokane or points beyond.

Rule 83(B) does not apply at Tacoma and Tide Flats Yard. Eastward trains will get Clearance Form A at Tacoma Jct.

See additional Special Instructions for Fourth Subdivision on Page 5.

		WES	TWA	RD	FIFTH SUBDIVISIO	N	EAST	WARD	7
8	Capacit; Sidings		Telegraph calls	Distance from Warden	Time Table No. 3  JUNE 7, 1959  STATIONS	Distance from Moses Lake	See Rule 6-A	Office Hours Also See Page 14 for Other Assigned Hours	
L			wx	0.0	WARDEN	23.2	JPRXY	8.00 AM to 5.00 PM Exc. Sat. & Sun.	A
		14		8.2	TIFLIS	15.0	JPXY	No Office	
		16		10.8	JARDINE	12.4		No Office	
	61	77		14.2	SIELER	9.0	P	No Office	
	17	23		17.2	McDONALD	6.0	P	No Office	
	24			19.2	GOODRICH	4.0		No Office	
A	57	350	МО	23.2	MOSES LAKE	0.0	PXY	8.00 AM to 5.00 PM Exc. Sat. & Sun.	L

## EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

Trains must not exceed a maximum speed of 40 M. P. H. between Warden and Tiflis: 35 M. P. H. between Tiflis and Moses Lake.

Rule 83(B) does not apply at Moses Lake.

INDUSTRIAL	TRACKS	NOT	SHOWN	AS	STATIONS
Name	м	liles	Directi	on	Stati
Scalley Spur		0.4	West		Sieler

			WES	TWA	RD	SIXTH SUBDIVISIO	N	EASTV	VARD		South out
		Capacity Sidings	011	Telegraph calls	Distance from Tiflis	Time Table No. 3  JUNE 7, 1959  STATIONS	Distance from Marcellus	See Rule 6-A	Office Hours Also See Page 14 for Other Assigned Hours	8	
	L	. 20			0,0	TIFLIS	38.7	JPXY	No Office	A	
		27			8.0	RUFF	30.7		No Office	W	
		28		_	13.8	MOODY	24.9		No Office		
		22			18.8	BATUM	19.9		No Office		
	_	22			22.7	3,9 LAUER	16.0		No Office		
		22			29.5	SCHOONOVER	9,2		No Office		
		21			33.9	PACKARD	4.8		No Office		
3 2	A	25			38.7	MARCELLUS	0.0	Y	No Office	L.	

# EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

Trains must not exceed a maximum speed of 25 M. P. H.

Rule 83(B) does not apply at Tiflis or Marcelius.

INDUSTRIAL TRA	CKS NOT	SHOWN AS	STATIONS
Name	Miles	Direction	Station
Laing	4.6	West	Tiflis Lauer
Reiman	2.0	West	Lauer

8	_		WES	TWA	RD	SEVENTH SUBDIVIS	EASTV	VARD	1	1	
		Capacit	y in cars		B	Time Table No. 3	from	8 2 2 2 3 3 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	Office Hours		
		Sidings	Other tracks	Telegraph calls	Distance from Beverly Jok	JUNE 7, 1959 STATIONS	Distance fr Hanford	See Rule 6-A	Also See Page 14 for Other Assigned Hours		
	L				0.0	BEVERLY JCT.	20.8	JPX	No Office	A	
6 15 15 10 10 10 10 10 10 10 10 10 10 10 10 10		21			4.0	LEVERING	16.8		No Office		
		60			14.4	PRIEST RAPIDS	6.4	PX	No Office		
	A				20.8	HANFORD	0.0	х	No Office	L	
				100	118	HANFORD YARD	8	PVXY	2		

Trains must not exceed a maximum speed of 30 MPH, except from one mile west of Levering to 4 miles west of Priest Rapids 20 MPH.
Rule 83 (B) does not apply at Hanford or Beverly Jct.

		INDUSTRIAL	TRACKS N	NOT SHOWN	AS	STATIO	NB
		Name	Mile	B Direc	tion		Station
М.	C.	S	10.8	West		_  Priest	Rapids

EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

		// // /*	WES	TWA	RD	EIGHTH SUBDIVISION	NC	EAST	WARD		
1	я	Capacity	y in cars	<u> </u>		Time Table No. 3	ш		Office Hours		
		Sidings	Other tracks	Telegraph calls	Distance from Cedar Falls	JUNE 7, 1959 STATIONS	Distance from Everett	See Rule 6-A	Also See Page 14 for Other Assigned Hours	1	
	L	100 20	Yard	мч	0.0	CEDAR FALLS	54.6	BJKOPRWXYZ	2.00 AM to 11.59 PM Except Sat., Sun. & Mon.	A	
5 2		i.	=,	1	8.9	TANNER (N. P. Crossing)	48.7	P	No Office	A n sema	= =
		67	19	5	8.0	NORTH BEND	46.6	PX	No Office		
			80	Q	11.2	3.2 SNOQUALMIE FALLS	43.4	PX	8.00 AM to 5.00 PM Except Sat. & Sun.		
			19	×	12.3	TOKUL	42.3		No Office		
2	20	= _5	8	=	18.9	FALL CITY	37.7	Р .	No Office		
2	8 1	92	20	, , , , , , , , , , , , , , , , , , ,	22.3	CARNATION	32.3	P	No Office		
		29	20	R res	31.0	BUVALL	23.6	P	No Office	3.25	
			10		36.6	HIGH ROCK	18.0	, a 1	No Office		
	A		¥		40.2	MONROE JCT.	14.4	JPVX	No Office	L	
				RO	40.5		14.1		2		
					47.4	SNOHOMISH	7.2		Via G. N. Ry.	5 g	
		Įv.		521 WA 19	53.2	LOWELL	1.4	JVX			
8 10	8		300		53.7	BELT YARD	1.9	JVXZ	Via. N. P. Ry.		
					53.2	LOWELL 1.4	1.4	JVX			
	<b>A</b> -y		Yard	RT	54.6	EVERETT	0.0	BKOPRX	8.00 AM to 5.00 PM Except Sat. & Sun.	L	E 10 70

Trains must not exceed a maximum speed of 30 MPH. between Cedar Falls and Snoqualmie Falls and between 2 miles east of Carnation and Monroe Jct., 15 MPH. between Snoqualmie Falls and 2 miles east of Carnation.

Rule 83 (B) does not apply at Monroe Jct. Eastward trains will obtain clearance Form A at Monroe.

EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

This time-table confers no authority between Monroe Jct. and Belt Yard. Between Monroe Jct. and Lowell. Great Northern Ry. Co. time-table and rules govern. Between Lowell and Belt Yard

via the Northern Pacific Ry. Co., the Northern Pacific Ry. Co. time-table and rules govern.

		WESTWARD			NINTH SUBDIVISIO	N	EASTV	VARD	Ça	9
	Capacity	y in cars	=7	(C:	Time Table No. 3	×				rigi. Kit
	Sidings	Other tracks	Telegraph calls	Distance from Bagley Jct.	JUNE 7, 1959 STATIONS	Distance from Enumelaw	Soe Rule 6-A	Office Hours Also See Page 14 for Other Assigned Hours		
L				0.0	BAGLEY JCT.	16.1	JPRX	No Office	A	4 8 9
		40		2.3	SELLECK	13.8	PX	No Office	až N	
				4.6	DURHAM	11.5		No Office		
			121	5.3	KANASKAT JCT.	10.8	JPV	No Office		
	11			7.4	2,1- PALMER	8.7		No Office		
	3	10		8.6	BAYNE JCT.	7.5	JPX	No Office	12	
		20		8.8	BAYNE	7.3	х	No Office		
				9.9	CUMBERLAND	6.2	10	No Office	, a	
	15			10.7	NACO	5.4		No Office		
		62		12.7	VEAZIE	3.4	P	No Office		
Ä		90	CW	16.1	ENUMCLAW	0.0	BOPRVXY	8.00 AM to 5.00 PM Except Sat. & Sun.	L	2

Trains must not exceed a maximum speed of 15 MPH. between Bagley Jct. and Bayne Jct. and 25 MPH. between Bayne Jct. and Enumclaw.

At Bayne Jct. and Kanaskat Jct. normal position of junction switch is for joint track between Bayne Jct. and Kanaskat Jct.

Rule 83(B) does not apply at Bagley Jct., Kanaskat Jct. or Bayne Jct.

A derail is located 330 ft. west of junction switch at Bagley Jct.

#### EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

) (1)			WES	TWA	RD	TENTH SUBDIVISIO	N	EASTV	/ARD		
	1	Capacit	y in cars		375	Time Table No. 3	а до		Office Hours		
		Sidings	Other tracks	Telegraph calls	Distance from Park Jet.	JUNE 7, 1959 STATIONS	Distance from Ashford	See Rule 6-A	Also See Page 14 for Other Assigned Hours		
	L	35	2 2	2 =	0.0	PARK JCT.	5.5	JPXY	No Office	٨	
			67		3.5	NATIONAL	2.0		No Office		
	A		80	3 - 8	5.5	ASHFORD	0.0	x	No Office	<b>L</b>	

Trains must not exceed a maximum speed of 20 MPH.

Rule 83(B) does not apply at Park Jct. or Ashford.

At Park Jct. trains and engines should proceed expecting to find cars on siding and on main track west from west switch of siding on Tenth Subdivision.

EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

10		WI	ESTW	/ARD		F	ELEVENTH SU	JBDI'	VISION	EASTWA	1RD		
Si	ECOND CLAS	55	1				Time Table					THIRD CLASS	5
563	791	863	Capacity	ty in cars	calls	E	No. 3	B 02		Office Hours Also See Page 14 for Other Assigned Hours	864	792	564
Time Freight	Way Freight	Time Freight	Sidings	Other tracks	raph	nce fr	JUNE 7, 1959	nce fr	See Rule 6-A	Assigned Hours	Time Freight	Way Freight	Time Freight
Daily Except Saturday	Daily Except Sunday	Daily Except Saturday	Sidings	trucks	Telegraph cults	Distance from Tacoma Jet.	STATIONS	Distance from Morton	*	\$ E	Daily Except Sunday	Daily Except Monday	Daily Except Sunday
564 L 10.35PM	L 7.30M	L 5.00AM	79		JN	0.0	TACOMA JCT.	66.5	JKPRVX	Continuous	A 10.00A	A 1.00PM	563 A 10.35PM
11.30	7.50	5.45		234		5.3	HILLSDALE	61.2	PX	No Office	9.40	12.40	10.15
11.50	8.15	6.00	119			9.0	ALLISON	57.5	P	No Office	9.30	12.20	10.05
A 11.59PM	8.27	A 6.15M	32	33		13.2	FREDERICKSON	53.3	JPRXY	No Office	L 9.20M	12.05PM	L 9.55PM
	8.55		72			19.8	THRIFT	46.7	P	No Оffice		11.35	
	9.08		30			23.0	TANWAX	43.5	P	No Office		11.25	
	792 10.00 10.45	=2 = 50 ×	,			33.6	EATONVILLE JUNCTION	32.9	JPXY	No Office		791 10.00 8.45	
	10.30		82	30		34.6	EATONVILLE	33.9	PX	No Office		9.45	
	11.15		92	20		41.5	NEW RELIANCE	25.0	PX	No Office		8.15	
	11.30		16	30	BE	46.5	ELBE	20.0	P	8.00 AM to 5.00 PM Except Sat. & Sun.		7.45	
	11.40		35			48.9	PARK JCT.	17.6	JPXY	No Office		7.20	
	12.45PM		27	220	D	53.0	MINERAL	13.5	PX	8.00 AM to 5.00 PM Except Sat. & Sun.		7.00	WAY 201 SE
	12.59		54	42		57.2	DIVIDE	9.3	PX	No Office		6.45	8
	1.20		15			64.4	COAL CANYON	2.1	P	No Office		6.10	
	A 1.30PW		60	155	MN	66.5	MORTON	0.0	BKRPVXY	8.00 AM to 5.00 PM Except Sat. & Sun.		L 6.00M	

Trains must not exceed a maximum speed of 30 MPH.

## EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

Automatic Block System is in use between Hillsdale and Tacoma Jct.

Rule 83(B) does not apply at Frederickson and Park Jct.

At Park Jct. trains and engines should proceed expecting to find cars on siding and on main track west from west switch of siding on Tenth Subdivision.

# INDUSTRIAL TRACKS NOT SHOWN AS STATIONS

Name	Miles	Direction	Station
Midland	1.5	East	Allison
Columbia Powder Co	0.7	West	Frederickson
Clay City Spur	8.2	East	Eatonville Jct.
Nineteen Creek	1.9	East	Coal Canyon

At Eatonville Jct. and Park Jct. the normal position of junction switch is for the Eleventh Subdivision.

At Frederickson the normal position of junction switch is for the Twelfth Subdivision.

			WES	TWA	RD	TWELFTH SUBDIVISION	ON	EAST	WARD	2 101 11	11
SECONE	1 1000000000000000000000000000000000000	Capacit	y in cars			Time Table No. 3		: E		THIRD	
563 Time Freight Daily Except Saturday	863 Time Freight Daily Except Saturday	Sidings	Other tracks	Telegraph calls	Distance from Frederickson	JUNE 7, 1959 STATIONS	Distance from Longview	See Rule 6-A	Office Hours Also See Page 14 for Other Assigned Hours	864 Time Freight Daily Except Sunday	564 Time Freight Daily Except Sunday
L 11.59N	L 6.15A	34	33	8J	0.0	FREDERICKSON	95.2	JPRXY	No Office	A 9.20M	A 9.55P
			19		3.4	LOVELAND	91.8		No Office	11 1250 1470	
12.20M	6.30	70		100 ESC	8.0	GREENDALE 7.8	87.2	P	No Office	9.04	9.38
12.45	6.45	20	50		15.8	McKENNA 7.6	79.4	P	No Office	8.48	9.22
1.01	7.00	33	12		23.4	RAINIER 5.5	71.8	P	No Office	8.32	9.06
1.15	7.10		85		28.9	SKOOKUMCHUCK	68.3	JV	No Office	8.21	8.55
1.20	7.14			JC	30.0	WESTERN JCT.	65.2	JVP	6.30 AM to 3.30 PM Except Sat. & Sun.	8.18	8.50
1.30	7.18	30			31.2	OFFUTT LAKE	64.0	P	No Office	8.15	8.45
A 2.00AM	7.30	30	39	V	37.2	MAYTOWN	58.0	JPRX	No Office	8.00	r 8.30
	864 7.45	51			44.6	ESSEX 5.0	50.6	P	No Office	863 7.45	47
2 2 2 2					49.6	(N. P. Crossing) (U. P. Crossing) BLAKESLEE JCT.	45.6	MX	1221 X		
	8.00	40	36	CN	50.9	CENTRALIA	44.3	PXZ	8.00 AM to 5.00 PM Except Sat. & Sun.	7.30	
	8.15	54	80	СН	54.6	(3 N. P. Crossings)  CHEHALIS	40.6	KMPRVX	6.30 AM to 3.30 PM Except Sat. & Sun.	7.15	gi e
	A 8.30M			JO	55.6	(N. P. Crossing) CHEHALIS JCT. 39.8	39.6	IJMPVX	10.00 AM to 7.00 PM Except Sat. & Sun.	L 7.00A	
	A 11.45AM				95.2	LONGVIEW	0.0		Via N. P. Ry.	L 4.30AM	

Trains must not exceed a maximum speed of 35 MPH. between Frederickson and Western Jct., 40 MPH. between Western Jct. and M.P. 16, 2 miles west of Centralia, 15 MPH. M.P. 16 and Chehalis Jct.

## EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

This time-able confers no authority between Chehalis Jct. and Longview, Northern Pacific Railway Co.'s time-table and rules govern.

Rule 83(B) does not apply to eastward trains at Chehalis Jct.
Unless otherwise provided, eastward trains must obtain clearance
Form A at Chehalis.

At Frederickson the normal position of junction switch is for the Twelfth Subdivision.

Rule 83(B) does not apply at Frederickson and Maytown.

At Maytown the normal position of junction switch is for the Twelfth Subdivision.

At Skookumchuck, trains will be permitted to move on Weyerhaeuser Timber Company's tracks between the hours of 9 P. M. and 6 A. M., for switching purposes only. Such movements must be protected as prescribed by Rule 99.

INDUSTRIAL	TRACKS NOT	SHOWN AS	STATIONS
Name	Miles	Direction	Station
UPCO	2.8	West	Offutt Lake

12	_		WES	TWA	ARD	THIRTEENTH SUBDIVI	EAST	WARD			
SECOND	ID CLASS					Time Table No. 3		ā		THIRD	CLASS
8 - 8-	563	Capacity	y in cars		from _	JUNE 7, 1959	from	See Rule	Office Hours Also See Page	564	=
I DOSCOLUMBIA	Time Freight	0.1.	Other	ųd <b>s</b>	ILM.	STATIONS	S E	6-A	14 for Other Assigned Hours	Time Freight	
Al a	Daily Except Sunday	Sidings	tracks	Telegraph calls	Distance fi Maytown	STATIONS	Distance Hoquiam			Daily Except Sunday	
	r 3.00m	30	39		0.0	MAYTOWN	56.6	JPRX	No Office	A 8.30PM	
	2.30	i	7		9.4	ROCHESTER (N. P. Crossing)	47.2	P	No Offi∞	8.05	
	A 2.40M				11.3	HELSING JCT.	45.3	JVR	No Office	L 8.00PM	
	5.15				53.0	ABERDEEN	3.6	P	Via U. P. Ry.	5.20	
	A 5.45AM	4	V L		56.6	HOQUAM	0.0	P	Via N. P. Ry.	L 5.00PM	

Trains must not exceed a maximum speed of 30 MPH.

#### EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

This time-table confers no authority between Helsing Jct. and Hoquiam. Between Helsing Jct. and Aberdeen. Union Pacific Railroad Co. time-table and rules govern. Between Aberdeen and Hoquiam, Northern Pacific Railway Co. time-table and rules govern.

Rule 83(B) does not apply at Maytown and Helsing Jct.

At Maytown the normal position of junction switch is for the Twelfth Subdivision.

At Helsing Jct. the normal position of junction switch is for the Union Pacific Railroad Co. track.

THIRD CLASS			2000	, ii	Time Table No. 3			handel Area	THIRD	CLASS
963	Capacit	y in cars		from Jet.	JUNE 7, 1959	8		Office Hours Also See Page	964	878
Way Freight	Sidings	Other	ųd∎.	lis Je	STATIONS	ond ond	See Rule 6-A	14 for Other Assigned Hours	Way Freight	
Daily Except Sunday	Sidings	tracks	Telegraph calls	Distance Chebalis	SIAITONS	Distance from Raymond	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	. T. e., 350 T	Daily Except Sunday	
1 E				0.0	CHEHALIS JCT.	46.2	IJMPVX	Via N. P. Ry.	ā <sub>1</sub>	
L 11.40	u I			16.9	DRYAD JCT.	29.3	JRVX	· No Office	A 9.10AN	
11.45		7		17.9	DOTY	28.3		No Office	9.05	
12.01	S	60		23.1	HILDA	23.1	х	No Office	8.45	
12.30		10		31.6	MACPHAIL	14.6	x	No Office	8.15	121
12.43	27			34.9	sutico	11.3	x	No Office	7.40	
12.49				36.5	FIRDALE 9.7-	9.7	x	No Office	7.30	
A 1.20P		Yard	RD	46.2	RAYMOND	0.0	BKORVXY	8.00 AM to 5.00 PM Except Sunday	L 7.00AM	- 5-1

Trains must not exceed a maximum speed of 20 MPH. between Dryad Jct. and MacPhail.
15 MPH. between MacPhail and Firdale, 20 MPH. between Firdale and Raymond.

# EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

This time-table confers no authority between Chehalis Jct. and Dryad Jct., Northern Pacific Railway Co.'s time-table and rules govern.

Rule 83(B) does not apply at Dryad Jct.

WESTWARD		RD	FIFTEENTH SUBDIVISION		EASTV	VARD	13			
	Capacity	in cars	= =		Time Table No. 3	11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		Office Hours	<u> </u>	
	Sidings	Other tracks	Telegraph calls	Distance from Bellingham	JUNE 7, 1959 STATIONS	Distance from Glacier	See Rule 6-A	Also See Page 14 for Other Assigned Hours		
<b>L</b>	9	Yard	ВМ	0.0	BELLINGHAM (4 G. N. Crossings)	46.8	BKMORTVXZ	8.00 AM to 5.00 PM 10.00 PM to d .00 AM Except Sat. & Sun.	A	327
	23			4.0	CORNWALL 7.4	42.8		No Office		
	38		17210U	11.4	WAHL 5.6	35.4	200 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 - 100 -	No Office		
2	23			17.0	STRANDELL 0.8	29.8		No Office		
= 19		30		17.8	EVERSON 1.5	29.0	х	No Office		
	25			19.3	HAMPTON	27.5	JXY	No Office		
	17			22.2	CLEARBROOK	24.6		No Office		
	21	Yard	SU	25.1	2.9 SUMAS	21.7	VXY	7.00 AM to 4.00 PM Except Sat. & Sun.	8 1	3 0
IN 1 A				26.1	(N. P. Crossing)	20.7		No Office		
	21			31.9	HILLTOP	14.9		No Office		
822		15		32.7	COLUMBIA	14.1		No Office		
			12. 11 11. 12. 11.	33.4	LIMESTONE JCT.	13.4	Y	No Office		
		12		36.3	KENDALL 3.2	10.5		No Office		
		15		39.5	MAPLE FALLS	7.3		No Office		
A	22	55		46.8	GLACIER	0.0	Y	No Office	L	8 7 8

Trains must not exceed a maximum speed of 25 MPH.

# EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

INDUSTRIAL T	RACKS NOT	SHOWN AS	STATIONS
Name	Miles	Direction	Station
Lind Spur	2.7	_LWest	Bellingham
Cement Spur	3.3	West	Bellingham
Bonneville Spur	3.2	West	Cornwall
Boulder Creek Spur	2.0	West	Maple Falls
Mt. Baker Mill Co	1.8	East	Glacier

A derail is located on main track west of west wye switch at Glacier.

Rule 83(B) does not apply at Glacier and Hampton.

WESTWARD				RD	SIXTEENTH SUBDIVIS	EASTWARD						
201	T		Capacit	y in care		· ·	Time Table No. 3	<b>x</b>	5 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8		and the second	
			Sidings	Other tracks	Telegraph calls	Distance from Hampton	JUNE 7, 1959 STATIONS	Distance from Lynden	See Rule 6-A	Office Hours Also See Page 14 for Other Assigned Hours	ar ar sawar	
*** = #\$	L	8 8 81		20		0.0	HAMPTON	5.4	JY	No Office	A	1992
e gara	A		343 H	Yard	LY	5.4	LYNDEN	0.0	R	8.00 AM to 5.00 PM Except Sat. & Sun.	L	

Trains must not exceed a maximum speed of 20 MPH. Over Slade Crossing 1.3 miles east of Lynden 3 MPH.

#### EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

Rule 83(B) does not apply at Hampton and does not apply at Lynden when operator not on duty.

14 WESTWARD						SEVENTEENTH SUBDIVISION EASTWARD					
SECONI	CLASS					Time Table No. 3		8		SECOND	CLASS
П	95	Capacit	y in cars		end end	JUNE 7, 1959	<b>8</b>	See Rule 6-A	Office Hours Also See Page	96	
	Way Freight	Sidings	Other tracks	qds.	Cowns		Soo Rule 6-A Also See Page 14 for Other Assigned Hours	14 for Other	Way Freight		
	Daily Except Monday	Sidings	URCES	Telegraph calls	Distance from Port Townsend	SIATIONS		9		Daily Except Monday	
	L 9.05A				0.0	PORT TOWNSEND	50.8	BVX	8.00 AM to 5.00 PM Except Sat. & Sun.	A 8.05AM	
	9.59	23			12.3	DISCOVERY JCT.	38.5	vx	No Office	7.15	
			10		13.5	MAYNARD	37.3	x	No Office		020 2
2		19			24.7	BLYN	26.1		No Office		
25 =	11.20	34	8		31.5	6.8 SEQUIM	19.3	a la	8.00 AM to 5.00 PM Except Sat. & Sun.	6.00	
			7		35.1	CARLSBORG	15.7	x	No Office		
			7		38.9	AGNEW	11.9		No Office		
			12		42.4	CRANE	8.4		No Office		
		23	599965		48.0	ENNIS CREEK	2.8	x	No Office		2714220000000000000000000000000000000000
n n e xix	A 12.30PM	ı	Yard		50.8	PORT ANGELES	0.0	BKORXYZ	8.00 AM to 5.00 PM Except Sunday	L 5.00AM	

Trains must not exceed a maximum speed of 15 MPH. between Port Townsend and Discovery Jct., 25 MPH. between Discovery Jct. and Port Angeles.

#### EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS

INDUSTRIAL	tracks not	shown as	STATIONS
Name	Miles	Direction	Station
Bekkvar	2.2	East	l Blyn

Rule 83(B) does not apply at Port Townsend.

C. P. MILES, W. H. SMITH, A. D. BRUNEAU,

L. H. BAILLY,

R. H. KOUBE, F. B. CEDERHOLM, G. C. COOPER,

Train Dispatchers.

R. E. BECK, Chief Dispatcher. R. L. MARTIN,

Trainmaster.

C. W. McMILLAN, C. L. SHAW, Travelling Engineers and Assistant Trainmasters.

## OFFICE HOURS NOT OTHERWISE SHOWN

F 52 = 1'				
STATION	SATURDAY	SUNDAY	MONDAY	HOLIDAY
Malden				7:00 AM to 4:00 PM
- 2				9:00 PM to 5:00 AM
Beverly	12:01 AM to 2:00 AM	12:01 AM to 2:00 AM		
	10:00 AM to 12:01 PM	10:00 AM to 12:01 PM		
Ellensburg	6:00 PM to 8:00 PM	6:00 PM to 8:00 PM		6:00 PM to 8:00 PM
Cedar Falls	7:00 AM to 3:00 PM	7:00 AM to 9:00 AM	7:00 AM to 11:00 PM	7:00 AM to 3:00 PM
Chehalis	7:00 AM to 9:00 AM	12:01 PM to 3:00 PM		12:01 PM to 3:00 PM
Chehalis Jct.		12:01 PM to 3:00 PM		
Raymond				8:00 AM to 5:00 PM
Bellingham	8:00 AM to 5:00 PM			8:00 AM to 5:00 PM
Sumas	8:00 AM to 10:00 AM			F = 0.
Port Angeles				8:00 AM to 5:00 PM

At stations where office hours are shown as continuous, such stations will be open continuous daily including Holidays.

At all other stations the office will be closed on Holidays unless hours are assigned as specified above or by bulletin.

Holidays include New Years, Washington's Birthday, Decoration Day, Fourth of July, Labor Day, Thanksgiving Day, and Christmas on day set by Proclamation.

#### YARD LIMITS AT

- Malden—Extend from 3099 ft. east of east switch to 5028 ft. west of west switch.
- Marengo—Extend from 3032 ft. east of east switch to 4976 ft. west of west switch.
- Othello—Extend from 3503 ft. east of east switch to 1000 ft. west of west switch of U and I Sugar Co. track.
- Moses Lake—Extend from 2000 ft. east of east wye switch to Airbase.
- Tiflis—Extend from 500 ft. west of west wye switch on Fifth subdivision to 500 ft. east of east wye switch and from east wye switch to 500 ft. west of west siding switch on Sixth Subdivision.
- Warden—Extend from wye switches to 3000 ft. west of industry track switch on Fifth Subdivision.
- Beverly and Beverly Jct.—Extend from 3700 ft. east of east switch Beverly to 245 ft. west of junction switch Beverly Jct. on Second Subdivision, and 5000 ft. west of junction switch Beverly Jct. on Seventh Subdivision.
- Kittitas—Extend from 3005 ft. east of east switch to 2989 ft. west of west switch.
- Cle Elum—Extend from 2613 ft. east of east switch to 4314 ft. west of west switch.
- Hyak & Rockdale—Extend from 3069 ft. east of east switch Hyak to 103 ft. west of west portal of Snoqualmie Tunnel.
- Cedar Falls—Extend from 2670 ft. east of east switch to 3895 ft. west of west switch on Third Subdivision, and 2900 ft. west of west switch of Log Loading track on Eighth Subdivision.
- Maple Valley—Extend from 3000 ft. east of east switch to Pacific Coast R. R. yard limits.
- Black River—Extend from 3063 ft. west of Northern Pacific Railway crossing to Pacific Coast R. R. and Union Pacific R. R. yard limits.
- Kent—Extend from 3000 ft. east of east switch to 1847 ft. west of west switch.
- Auburn—Extend from 3007 ft. east of east switch to 2600 ft. west of west switch connection to Government Yard.
- Sumner—Extend from 3088 ft. east of east switch to 2994 ft. west of west switch.
- Tacoma, Tacoma Jct. & Hillsdale—Extend from 3500 ft. east of east siding switch at Tacoma Jct. to end of track at Tacoma and Tide Flats Yard on Fourth Subdivision and to 1608 ft. west of west switch Hillsdale on Eleventh Subdivision.
- Priest Rapids—Extend from 2000 ft. east of east switch to 2000 ft. west of west switch.
- Hanford—Extend from Hanford Station Sign (MP 20.79) to 3000 ft. west of west switch Hanford Yard.
- North Bend-Extend from east switch to 3500 ft. west of west switch.
- Snoqualmie Falls—Extend 3100 ft. east of east switch to 2692 ft. west of west switch.
- Monroe Jct.—Extend from 5300 ft. east of junction switch to Monroe Jct.
- Everett & Belt Yard—Extend from Lowell Jct. to end of track Everett and Belt Yard N. P. Ry. connection to end of track.
- Bagley Jct.—Extend from Bagley Jct. switch to 800 ft. west of switch on Ninth Subdivision.
- Selleck—Extend from 2263 ft. east of east switch to 3120 ft. west of west switch.

- Bayne—Extend from 2774 ft. east of Occidental spur switch to 2627 ft. west of Bayne Mine switch.
- Enumclaw—Extend from 1288 ft. east of east wye switch to 2025 ft. west of west switch of Northern Pacific siding and to 1300 ft. east of interchange east switch White River Lbr. Co. R. R.
- Frederickson—Extend from 493 ft. east of east switch to 3250 ft. west of west switch on Eleventh Subdivision, and 2672 ft. west of west switch on Twelfth Subdivision.
- Eatonville Jct. and Eatonville—Extend from 2500 ft. east of east switch to 2500 ft. west of west switch Eatonville Jct., and to end of track west of Eatonville.
- New Reliance—Extend from 1000 ft. east of east switch to 2500 ft. west of west switch.
- Park Jct.—Extend from 3060 ft. east of east switch to 2860 ft. west of west switch on Eleventh Subdivision, and 6468 ft. west of west switch on Tenth Subdivision.
- Mineral—Extend from 1438 ft. east of east switch to 1473 ft. west of west switch.
- Divide—Extend from 2500 ft. east of east switch to 3500 ft. west of west switch.
- Morton—Extend from 2578 ft. east of east switch to Kosmos Logging Co. interchange.
- Ashford-Extend from 242 ft. east of east switch to end of track.
- Maytown—Extend from 2874 ft. east of east switch to 1347 ft. west of west switch on Twelfth Subdivision, and to 3279 ft. west of west switch on Thirteenth Subdivision.
- Centralia & Blakeslee Jct.—Extend from 512 ft. east of N. P. Ry. crossing at Blakeslee Jct. to 3555 ft. west of west switch Centralia.
- Chehalis—Extend from 2975 ft. east of east switch to N. P. Ry. and C. C. & C. Ry. connection.
- Dryad Jct.—Extend from junction switch to 1500 ft. west of junction switch.
- Hilda—Extend from 1500 feet east of east switch to 1500 feet west of west switch.
- MacPhail—Extend from 2476 ft. east of east switch to 2000 ft. west of west switch.
- Firdale—Extend from 3500 feet west of M.P. 56 to 1000 ft. east of east switch at Sutico.
- Raymond—Extend from 4230 ft. east of east switch to end of track.
- Port Angeles & Ennis Creek—Extend from 2500 ft. east of east switch at Ennis Creek to 1500 ft. west of Bayside yard switch.
- Carlsborg—Extend from 2500 ft. east of east switch to 2500 ft. west of west switch.
- Maynard and Discovery Jct.—Extend from 1500 ft. west of switch Maynard to 1000 ft. east of east switch Discovery Jct.
- Port Townsend—Extend from 2500 ft. west of west main line switch, east to end of yard tracks.
- Bellingham—Extend from 2000 ft. west of Cement Plant switch to end of tracks, including Lake Line, Bellingham.
- Everson & Hampton—Extend from 2000 ft. east of east switch Everson to 2008 ft. west of west wye switch Hampton.
- Sumas—Extend from 1954 ft. east of east wye switch to 2000 ft. west of west wye switch.

# LOCATION OF EMERGENCY TELEPHONES AT AND BETWEEN STATIONS

Malden—Room East of waiting room and on pole at west switch.

Pine City-Section house.

Kenova-East switch. Rock Lake-Station board.

LaVista-East and west switches.

Ewan-Elevator.

Between Ewan and Revere-Mile post 1908.

Revere-East and west switches.

Paxton-West switch south side.

Between Paxton and Marengo-Mile post 1922.

Marengo-Section house.

Hillcrest-Station board.

Ralston—Depot baggage room and west switch.

Pizarro—Station board.
Vassar—East and west switch.

Lind—East switch and depot baggage room.

Servia-East and west switch.

Roxboro-East switch and west switch.

Warden-Section house, depot baggage room and west switch.

Novara-East and west switch.

#### SECOND SUBDIVISION:

Othello—East and west switch at roundhouse and car department.

Taunton-Substation.

M.P. 1999-6-Phone box, Slide area.

Corfu—East switch phone box and section house.

Smyrna—East switch phone box section house and depot.

M.P. 2023—18 pole lengths east of M.P. 2023.

Beverly-East switch phone box, section house and cafe.

Columbia River Bridge—West end phone box.

M.P. 2029-6 pole lengths west phone box.

Doris—Substation and west switch phone box. Rye—West switch phone box.

M.P. 2043—8 pole lengths east phone box.

Boylston—Section house and west switch phone box. M.P. 2049—12 pole lengths west phone box.

East Kittitas-Scale house.

Kittitas-Substation.

Ellensburg-Baggage Room.

Thorp—East switch and west switch phone boxes.

Taneum—Watchman's shanty, 1/2 mi. west of M.P. 2070.

Tunnel 47-Just east of M.P. 2073 phone booth.

Horlick-East switch and west switch phone boxes and section

Riverside—Just east M.P. 2079 and M.P. 2080 phone boxes. Cle Elum—Section house, substation, and west switch phone box.

#### THIRD SUBDIVISION:

Signal 5-7-10 pole lengths west of M.P. 2091 phone box.

Easton—East switch, baggage room and section house.

Bridge 18-M.P. 2100 phone booth.

M.P. 2104—6 pole lengths east phone box.

Whittier-East switch phone booth, west switch phone box and

section house.

Meadow Creek—Signal 23-0 phone box.
Roaring Creek—1/4 mi. west of M.P. 2110.
Keechelus Snow Shed—West end phone booth.

Hyak-East switch phone box, section house, substation, baggage

room and Signal Mtr.'s house.

Rockdale—East switch phone box and west switch phone booth.

Humpback Snow Shed—100 feet west phone box. Windy Point—1/2 mi. west M.P. 2120 watchman's shanty.

Bandera—East switch watchman's shanty, west switch phone box.

Harris Creek-Phone booth Signal 42-3, M.P. 2124.5.

Minot-Watchman's shanty.

Garcia—Section house, depot and west switch phone booth.

Hull Creek-3 pole lengths east of Change Creek Bridge.

Ragnar-East switch and west switch phone booths.

Cedar Falls-Substation, waiting room and west switch phone booth.

Bagley Ict.—Phone booth.
Barneston—West switch phone booth.

Trude—East switch and west switch phone booths.

Landsburg-1/2 mi. west M.P. 2148.

Maple Valley-Section house, east switch phone box and 2 mi. west near M.P. 2156 phone box.
Cedar Mountain\*—Overhead highway crossing phone box.

Indian\*—East switch and west switch phone boxes.
Ellict\*—Phone box, 1 mi. east phone box, Bridge 14-2 1 mi. west. 13-4 Old Bridge 7 phone box.

Renton\*-East switch and west switch phone boxes, outside depot

Black River\*—East switch yard phone box, N.P. transfer phone box. Boeing Bridge\*—Signal 7-2 phone box. Davis Crossing\*—Phone box.

Van Asselt\*-East end yard.

\*—These phones connected to the Pacific Coast Dispatcher at Maple Valley only.

## FOURTH SUBDIVISION:

Black River Intg. Plant—W.B. home signal.

Black River Jct.—Yard office. Black River—N.P. crossover phone box.

Orillia—Highway crossing phone box.

Kent—East switch and west switch phone boxes and freight house. Auburn-East switch phone box freight house east siding switch,

and west Army point switch phone box. Benroy-East switch phone box.

Sumner-Freight house.

Puyallup-East and west switch.

#### FIFTH SUBDIVISION:

Tiflis-East junction switch. Sieler-Pole box east switch. Scalley Spur-Switch. MacDonald-Pole box east switch. Moses Lake-Section Foreman's House.

#### SEVENTH SUBDIVISION:

M.P. 9-2 pole lengths east phone box. Priest Rapids-Station house.

#### EIGHTH SUBDIVISION:

Tanner—In box on pole just west main highway crossing.

North Bend—Section house. Snoqualmie Falls—East switch phone booth and baggage room.

Fall City-Phone box.

Carnation—East switch phone booth and section house.

Duvall—Phone box.

Monroe Jct.-G.N. phone booth.

Everett-Roundhouse.

#### NINTH SUBDIVISION:

Selleck-Phone booth.

Kanaskat Jct.-Phone booth. Bayne Jct .- Phone booth.

Veazie-N.P. booth, also N.P. phone.

Enumclaw-Baggage room.

#### **ELEVENTH SUBDIVISION:**

Tacoma—On pole east end of Bridge C Street.

Hillsdale—Phone booths near 60th, 64th and 72nd Streets.

Bridge GG-46-Small building.

Allison-Booth near west switch.

Frederickson-Depot.

Thrift—In building near west switch.

Tanwax—On pole at east switch.

Kapowsin-Section house.

Clay City-Box on pole near loading platform.

Eatonville Jct.—Depot.

New Reliance—Phone booth near west switch at highway crossing.

Elbe-Freight house.

Park Jct.—Phone booth near east switch. Old Burt.—On pole in box.

Mineral—Depot waiting room and section house.

Divide-Phone booth near east switch. 19 Creek—Phone booth near east switch.

Coal Canyon-Phone box on pole near east switch.

# LOCATION OF EMERGENCY TELEPHONES AT AND BETWEEN STATIONS—Continued

#### TWELFTH SUBDIVISION:

Greendale—Phone box near west switch.

McKenna—West switch
Rainier—Freight house.

Offutt Lake—Phone box or pole near west switch.

Maytown—Freight house and section house.

Essex—Phone booth near west switch.

Centralia—Freight house.

Chehalis—Section house.

#### THIRTEENTH SUBDIVISION:

Rochester-In Tool house, near R. R. crossing.

#### FOURTEENTH SUBDIVISION:

Doty—City phone in section house. Firdale—City phone in section house.

#### FIFTEENTH SUBDIVISION:

Wahl—Middle of siding. Everson—Freight house. Hampton—Freight house. Sumas—Freight house.

# LOCATION OF PORTABLE TELEPHONES ON FOLLOWING TRAINS:

Nos. 15 and 16-In locker baggage end of dormitory car.

#### TROLLEY CUT OUT SWITCHES

At stations where substations are located the air gaps are near substations, and the switches are located in the substations. At other stations switches are located near each end of siding or yard except:

Othello, west Switch

825' west of west H.B.

Jericho, Switch No. 9 \_\_\_\_\_\_2400' west of west H.B. Tunnel 45, Switch No. 18\_\_\_\_\_\_1550' east of tunnel Boylston, Switch No. 19 400' east of east H.B. East Kittitas, Switch No. 21\_\_\_\_\_\_2.8 miles east of east switch Kittitas Insulated Yard.....Controlled from Substation Tunnel No. 47, Switch No. 28.\_\_\_\_\_500' west of tunnel Cle Elum Insulated Yard......Controlled from Substation Keechelus snowshed, Switch No. 38\_\_\_\_\_\_1325' west of shed Garcia, Switch No. 44\_\_\_\_\_\_875' east of east H.B. Cedar Falls Insulated

Renton, Switch No. 60250	east of double track H.B.
Black River, Switch No. 66	
Black River, Switch No. 101 controlling	
inhound track	650' north of O-W tower

Argo, Switch No. 105 controlling

inbound P.C. track \_\_\_\_\_at P.C.-O-W crossover Argo, Switch No. 106 controlling

outbound P.C. track\_\_\_\_\_at P.C.-O-W crossover

Argo, Switch No. 107 controlling inbound O-W track at P.C.-O-W crossover

Trolley Switches Nos. 107 and 108 may be operated by remote control switch located in U.P. Tower, Argo.

Seattle Psgr. Station, No. 109 controlling

Seattle Pagr. Station. No. 110 controlling

Switches 105, 106, 107, 108, 109 and 110 can be opened under load if necessary for protection of persons or property.

Kent, Switch No. 70 1375' west of west H.B. Auburn, Switch No. 73 650' west of west H.B.

#### TONNAGE CHART

	tonnage rating—east	9 B V V V V V V V V V V V V V V V V V V		EF-2	573	an garaga water ya Garan ah Bada ta Tanga wateriya
		EP-2	EF-1	EF-3	EF-5	
	Tacoma to Black River	3450	CL	CL	CL	
	Black River to Cedar Falls	2000	4100	5500	8200	
	Cedar Falls to Hyak	1250	1700	2550	3400	
	Hyak to Cle Elum	CL	CL	CL	CL	
	Cle Elum to Kittitas	4000	6000	7500	12000	
	Kittitas to Boylston	1300	1670	2500	3340	
	Boylston to Beverly	1300R	1670R	2500R	3340R	
	Beverly to Othello	3200	5000	7000	10000	
	TONNAGE RATING—WEST			nga waa wanga Sag		
	Othello to Beverly	CL	CL	CL	CI	
	Beyerly to Boylston	980	1400	2100	2800	
	Boylston to Kittitas	1400R	3100R	4650R	6200R	
	Kittitas to Cle Elum	3700	5000	7000	10000	
	Cle Elum to Hyak	3200	4000	5500	8000	
	Hyak to Cedar Falls	1250R	2800R	4000R	5600R	
	Cedar Falls to Black River	CL	CL	CL	CL	
THE RESERVE TO SECURE THE SECURITY OF THE SECU	Black River to Tacoma	3450	CL	CL	CL	

Dispatcher may increase or decrease above tonnage ratings as may be necessary.

# SURGEONS MILWAUKEE HOSPITAL ASSOCIATION

Dr. J. F. DePree	Chief Surgeon	Seattle
Dr. W. F. Hoffman	Oculist	Seattle
Dr. E. DeMar Anderson	Oculist	Seattle
Dr. J. M. Shiach	Oculist	Seattle
Dr. D. G. Willard	District Surgeon	Тасота
Dr. A. W. Howe	Oculist	Tacoma
Dr. S. S. Thordarson	Oculist	Tacoma
Dr. Robert F. Kaiser	Oculist	Bellingham
Dr. H. D. Waltz	Oculist	Everett
Dr. W. W. Hicks	Oculist	Ellensburg
Dr. J. M. Nelson	District Surgeon	Spokane
Dr. Carroll Smith	COMPANY OF THE PARTY OF THE PAR	and the same of th
Dr. R. L. Pohl	Asst. Oculist	Spokane

# HOSPITALS

Ellensburg	_Ellensburg General	Hospital
Cle Elum	Roslyn Cle Elum	Hospital
Everett	Providence	Hospital
Seattle	Providence	Hospital
Port Angeles	Olympia Memorial	Hospital
Tacoma	St. Joseph's	Hospital
Тасота	Doctors'	Hospital
Hoquiam	Hoquiam	Hospital
Chehalis	St. Helen's	Hospital
Bellingham	St. Luke's	Hospital
Spokane		

Stretchers are located as follows: Malden, Spokane, Lind, Othello, Beverly, Ellensburg, Cle Elum, Hyak, Cedar Falls, Tacoma, Morton, Mineral, Black River.

LOCATION	NAME	TITLE	OFFICE TELEPHONE	RESIDENCE TELEPHONE
Spokane	*Dr. J. M. Nelson	Dist. Surgeon	MAdison 4-5351	KEystone 4-8200
Spokane	*Dr. C. L. Kyle	Local Surgeon	MAdison 4-7744	FAgirfax 8-7581
Spokane	*Dr. E. G. Peacock	nogur burgoon	MAdison 4-2136	MAdison 4-6880
Rosalia	Dr. O. I. Lowry	" "	13-2061	13-2066
Moses Lake	Dr. K. P. Conklin		RO 5-3433	RO 5-5273
Ritzville	Dr. J. C. Lindsay	" "	100 0-0100	110 0 0270
Othello	Dr. K. Q. Pershall	" "	HU 8-3812	HU 8-3811
Othello	Dr. G. Love	Asst. Surgeon	110 0-0012	110 0-0011
Ellensburg	*Dr. Carl W. Olander	Local Surgeon	WOoland 2-1461	WOoland 2-4601
Ellensburg	Dr. R. M. Hill	Asst. Surgeon	WOoland 2-1461	WOoland 2-3327
Ellensburg	Dr. R. H. Welding	ingui burgou	WOoland 2-1461	WOoland 2-6651
Ellensburg	Dr. J. W. Devney	,, ,,	WOoland 2-1461	WOoland 2-3657
Cle Elum	*Dr. J. P. Mooney	Local Surgeon	Roslyn 61	Roslyn 635
North Bend	Dr. J. O. Borgen	nocar bargeon	88-1771	88-1381
Snogualmie	Dr. F. R. Sutherland	" "	88-3352	88-3535
Snoqualmie Snoqualmie	Dr. I. L. Whitaker	" "	88-3352	88-3423
Fall City	Dr. Irene C. Werthman	" "	00-3332	00-3423
Carnation	Dr. P. O. Hermann	" "	28 03	a figure of the part
		" "	PYramid 4-3931	PYramid 4-6931
Monroe	Dr. P. P. Cooley			
Everett	*Dr. A. H. Gunderson	,, ,,	ALpine 2-0123	ALpine 2-0123
Enumclaw	Dr. E. R. Tiffin	,, ,,	TAylor 5-2222	TAylor 5-3809
Renton	Dr. F. W. Reebs	, ,,	ALpine 5-2451	S1
Renton	Dr. H. H. Adams		ALpine 5-3232	GTT 1 4 0001
Seattle	*Dr. J. F. DePree	Local Surgeon	MAin 3-3037	SUnset 4-3921
Seattle	Dr. H. M. Hackedorn		MAin 2-3003	GLencourt 4-315
Seattle	*Dr. I. M. Cohn	Asst Surgeon	MAin 3-2839	ATwater 2-9414
Seattle	*Dr. Wm. C. Speidel	Local Surgeon	MAin 2-1291	PArkway 2-0240
Kent	Dr. J. O. Taylor	" "	ULrick 2-3700	ULrick 2-0568
Auburn	Dr. John Darst	" "	TEmple 3-1680	TEmple 3-3354
Aubum	Dr. E. K. Giere		TEmple 3-3260	TEmple 3-4660
Puyallup	Dr. E. F. McCabe	" "	THorndyke 5-6682	THorndyke 5-817
Sumner	Dr. J. M. Kanda	" "	UNiversity 3-4162	UNiversity 3-4430
Tacoma	*Dr. D. G. Willard		Broadway 2-4197	Market 7-0630
Tacoma	*Dr. S. E. Adams	Asst. Surgeon	Fulton 3-1559	Skyline 2-1492
Tacoma	*Dr. G. G. McBride	" "	Broadway 2-5385	Skyline 9-7564
Tacoma	*Dr. A. J. Hermann	" "	Broadway 2-1419	Skyline 9-4632
So. Tacoma	Dr. F. P. Hoskins	" "	Greenfield 4-9300	Skyline 9-0924
Eatonville	Dr. D. M. Nevitt	Local Surgeon	TErrace 2-3111	TErrace 2-3116
Aberdeen	Dr. K. D. Graham	" "	407	3450
Chehalis	Dr. L. G. Steck		SHerwood 8-7143	SHerwood 8-4332
South Bend	Dr. J. C. Proffitt	" "	TRinity 5-5614	TRinity 5-5722
Longview	Dr. J. L. Norris	" "	HAmilton 3-1510	HAmilton 5-4020
Port Townsend	Dr. H. G. Plut	" "	370	483
Port Angeles	*Dr. R. S. Hamilton	" "	GLencourt 7-9411	
Port Angeles	*Dr. Albert R. Mangan	" "	GLencourt 7-4761	GLencourt 7-4631
Bellingham	*Dr.W. C. Moren	" "	REgent 4-5990	
Bellingham	*Mr. M. E. Altman	" "	REgent 4-4380	REgent 4-0694
Everson	Dr. K. H. Spady		WOodland 6-3441	

<sup>\*</sup>Examining Surgeons

<sup>\*\*</sup>Re-examinations only

# SPECIAL INSTRUCTIONS

# **ALL SUBDIVISIONS**

G1 Engineers operating engines equipped with the oscillating emergency red headlight will be governed by the following:

When the air brakes are applied from any cause other than in normal operation by the engineer, or when it is found necessary to stop train due to some defect, or under circumstances which might cause a derailment and the fouling of adjacent main track, engineer must immediately display the oscillating red headlight.

Engineers on approaching trains will take notice and immediately bring train to a stop, and will not proceed until track is found to be safe and clear for their movement.

These instructions are applicable at all times, both day and night. The emergency headlight should not be used for any other purpose.

The operation and use of this device does not in any way relieve trainmen and enginemen from full compliance with Rules 99 and 102.

Emergency Red Rear End Lights, Trainmen on trains equipped with oscillating emergency red rear end lights must familiarize themselves with the location of the switches which control the lights and will be governed by the follow-

The emergency red rear end light will be used on trains so equipped in the following manner:

To provide protection to trains on adjacent tracks as required by Rule 102.

To provide supplemental protection under Rule 99 in all circumstances where its use is necessary to stop following trains on one or more tracks.

A following train observing this emergency red light displayed must immediately reduce to restricted speed and be governed by instructions of flagman.

The use of this emergency red light does not in any way relieve the flagman from full compliance with Rules 99 and

Portable emergency red lights must be removed before coupling onto the car.

G2 The Mars white light on engines so equipped shall be used at all times between the hours of sunset and sunrise, and during daylight hours on days that are dark, or during sleet, snow, fog or rain, such as would impair the vision of motorists and hinder them from observing approaching trains, except the light must be turned out when moving through certain portions of large terminals and yards where yard engines are employed, approaching junctions, or meeting points, or while standing at those points, and when approaching trains in the opposite direction on double or three or more tracks.

In case of failure of the regular headlight, the Mars white light should be used in stationary position as the headlight.

G3 Where Approach signals are used in connection with facing point switches or manual block signals, the switch or block signal will be considered as the Home signal.

G4 Employes are prohibited from:

Removing any of the appliances of engines or cars that will endanger the safety of themselves or others.

Standing on top of high cars while passing under bridges or through tunnels.

Getting on the end of an engine or of a car as it approaches them.

Going between or running ahead of moving cars to couple. uncouple, open, close, or arrange knuckles of couplers.

Working on the side of cars or trains where there are buildings, sheds, cattle chutes, or other projections.

Kicking or holding draw bar in position to make a coupling with an approaching car or engine.
Following other dangerous practices.

- G5 When, for any reason, adjustment is necessary to a drawbar, knuckle pin, or locking block prior to making coupling or when coupling does not make, the engine or cars must be separated not less than 20 feet and action taken to prevent the cars from moving before going between the cars to make the adjustments.
- G6 Whenever a car without a drawbar or draft timber is to be moved by a train or engine and it is necessary to chain the car to other cars or engines, employes are prohibited from going between such car and other cars or engines until the persons performing the work have a thorough understanding with the engineer and other members of the train crew. During the process of chaining up the car, the car itself must be properly secured while being chained to other cars, and if the car is to be chained to the engine, then the car must be secured and the brakes on the engine set to avoid a movement of any kind. The engineer must not release the brakes until he has received verbal information that all employes are out from between the cars or engines, and under no circumstances must employes again go between such car or cars and engines until the engineer and other members of the train crew have been notified and the car properly secured and the engine brake set.
- G7 Employes must not handle or board cars or engines that bear BAD ORDER cards without first ascertaining the nature of the defect so that they may guard against injury.
- G8 When using handholds and ladders or stirrup steps to descend from engines, cars or other equipment, employes must face the equipment and be sure of a secure handhold and footing.
- G9 Employes must not step on track rails nor other similar objects when it can be avoided.
- G10 When run-ways, gang-planks or skids are used in handling freight to or from cars, they must be secured to prevent slipping.

G12 Employes are prohibited from riding:

On engine footboards or pilot steps between engine and car when cars are being pushed.

On leading footboard or pilot steps while coupling engine to

On deadwoods, drawbars, brake beams, journal boxes and brake wheels.

On ends of cars containing lading which may shift.

On engine pilot or footboards, sides or ends of cars, while going in or out of depressed tracks.

On forward footboard or pilot steps of engine in direction the engine is moving except in cases where operating conditions make it necessary for safety and then only one employee must ride on the footboard.

In the gangway of engines.

- G13 When necessary to go outside when locomotive is either standing or moving, extreme caution must be exercised to avoid slipping or falling from cab ledge (catwalk) or running board. Cab ledge (catwalk) is not to be used on standing locomotives when access to the running board can be had by other means.
- G14 The use of gasoline stoves and burners in Company's buildings and equipment is prohibited.

The use of oil and bottled gas (propane) stoves and burners for either cooking, heating or refrigeration is permitted only when authorized by the Company and when installation is made in accordance with Company standards.

The above does not apply to U.S. Army Field Ranges when installed under the supervision of a U.S. Army Commissioned Officer and operated by his men.

To avoid personal injuries and possible damage by fire, when lighting and operating Ajax Baughan caboose oil stoves, employes must be governed by the instructions which are posted in each caboose so equipped.

- G15 The provisions of Rule 815 also apply to transfer movements within yards.
- G17 The following cars, loaded or empty, will be handled next ahead of the caboose giving preference in the order shown, except that at least one car must be handled between a flat car loaded with rails and the caboose:

Bad order cars. Switch rear "S.R." cars.

- G18 Unoccupied outfit cars of steel underframe or steel center sill construction when inspected and passed by a Car Department inspector, may be hauled in any part of the train.
- G19 For the comfort of the passengers, the air-conditioning on our air-conditioned passenger trains should be kept operating as long as possible. When approaching stations where cars are to be picked up or set out between the engine and the rear car, the steam line must be blown out at the proper place and the steam shut off before the train stops. At the final terminal of the equipment, when no cars are to be set out between the engine and the rear car, the fireman will simply shut off the steam as soon as the train stops in the station.
- G20 In case of heavy rain or violent windstorm, the operator must notify the section foreman.
- G21 A yellow flag by day stencilled ELECTRIC CHARGE LINE and in addition, a yellow light by night, placed at one or both ends of a passenger car standing on a yard track, indicates that the battery of the car is connected to a charge line. When thus protected, it must not be coupled to or moved before the charge line has been removed. Other quipment must not be placed on the same track so as to intercept the view of the yellow signals without first notifying the workmen; in the absence of the workmen, the signals may be moved to the end of the equipment so placed to afford the necessary protection.

#### **DEFINITIONS**

G22 Centralized Traffic Control.—A block or a series of consecutive blocks, the signals of which, together with certain switches, are controlled from a central location.

Remote Control Interlocking.—A system of operating outlying signal appliances from a designated point.

C.T.C.—Abbreviation for Centralized Traffic Control.

# CENTRALIZED TRAFFIC CONTROL

- G23(a) On portions of the railroad so specified in the timetable, trains will be governed by block signals whose indications will supersede the superiority of trains for both opposing and following movement on the same track.
  - (b) Except as affected by Special Instructions G23 (a), all block signal rules and operating rules remain in force.
  - (c) The movement of trains and engines will be supervised by the Train Dispatcher, who may also control the CTC. When the CTC is controlled by other than the Dispatcher, the Dispatcher will issue the necessary instructions to the operator at the control station, location of control station will be designated by special instructions.
  - (d) Trains or engines must not enter CTC territory unless the governing signal displays a Proceed indication or unless authority is obtained from the authorized employe at the control station.
  - (e) In case of failure of a Stop signal, authority to proceed will be issued orally by the authorized employe at the control station.
  - (f) Trains or engines must not move beyond the limits of CTC territory without the proper authority including the information required by Rules S-83 and D-83.
  - (g) When the governing signal displays a Stop indication and the operator knows that the interlocked switches are in proper position and there are no opposing or conflicting train or engine movements involved, he will authorize the train or engine to proceed in the following form:

"You may proceed at restricted speed to the next signal,"

If the operator does not positively know that there are no opposing or conflicting train or engine movements involved or that the interlocked switches are in proper position, he will issue authority to proceed in the following form:

"You may proceed under protection of a flagman to the first signal that displays a Proceed indication." These instructions must be repeated by the conductor or engineer to insure correct understanding. See Rule 663(A).

- (h) When the governing signal displays a Stop indication for an approaching train or engine and the means of communication have failed, the train or engine may proceed at restricted speed, when preceded by a flagman, to the next signal that displays a Proceed indication, or to the next point of communication, Flagman must be sent far enough in advance to insure full protection.
- (i) Where main track switches are not interlocked or equipped with electric locks, when a train or engine enters a siding or other track or makes a crossover movement, the operator in charge must be notified when the movement is complete and the main track switches have been closed and locked. The switches must not be opened nor will the train or engine enter upon or foul the main track without first receiving authority from the operator.
- (j) A train or engine must not move in the opposite direction to that authorized by the governing signal without proper authority from the operator, unless preceded by a flagman sent far enough in advance to insure protection.
- (k) Instructions for the operation of the electric locks on hand operated switches are posted in telephone booths or on the inside of the door of the locks.
- (1) Dual Control switches are located at Interlocking in C.T.C. territory. See Rules 663 (A), 663 (B) and 663 (C).

# GENERAL SPEED RESTRICTIONS

- G24 When freight cars (except cars that are equipped for passenger train service) are hauled in a passenger train, the maximum speed of that train will be that prescribed for freight trains in that territory unless a different speed is authorized by bulletin or train order.
- G25 Diesel or electric engines with unobstructed view in either direction may be operated at permissible speeds in either direction.

Diesel or electric engines with restricted view in one direction must, when operated in that direction, reduce speed to the extent necessary for safe operation.

G26 Diesel engines moving dead in train will come under the provisions of Rule 806 and when the doors of the locomotive are locked and the hand brake is not accessible, a freight car with operative hand brakes must be coupled to the diesel with uncoupling mechanism made inoperative.

The provisions of Rule 806 will apply to oil carrying locomotive tenders X-908160, X-908167 to X-908171 inclusive. These tenders are equipped with roller bearings and when set out must be properly secured to prevent their moving.

G27 When diesel-electric or electric engines are handled dead in train, the following will apply:

When engine handling the train is of the wagon type:—Single unit diesel-electric road switcher, yard switcher or wagon type units may be handled next behind the road engine.

When engine handling the train is of the road switcher or yard switcher type:—Wagon type units or series of such units may be handled next behind the road engine, but road switcher and yard switcher type engines must be separated from the road engine by at least one car and must be separated from each other by one or more cars.

Diesel-electric or electric engines will be handled dead in train on authority of Chief Dispatcher who will specify the train they are to be handled on and where they will be placed in the train.

When a 44-ton diesel engine is being handled dead in freight train, it must be placed at rear of train just ahead of the caboose and when a pusher engine is placed on the rear of the train, the 44-ton diesel engine must be placed behind the pusher. When there is a 44-ton diesel engine on the rear of the train, the train must not be pushed nor pulled from the rear and the dead diesel engine must not be handled in switching movements in conjunction with other cars.

G28 Diesel engines must not be towed or operated under own power through water over three inches above the rails. When towed or operated under own power through water above rails, a speed of 3 M.P.H. must not be exceeded.

Passenger car equipment may be moved through water up to six inches above the top of rail without damage to the generators or battery and bearing boxes.

When necessary to move passenger car equipment through water from 3 to 6 inches above the rails, the equipment should be pushed through the water to a point where it can be reached from the opposite end by a power unit or other equipment and pulled on through the obstruction.

G29 When two or more diesel engine units are coupled together the numerals and suffix letter of the leading unit will be illuminated at all times when in service. The numerals and suffix letter of trailing units must not be illuminated.

The number and suffix letter of the leading unit only to be used in train orders.

G30 Unless otherwise restricted, the following equipment must not be moved in excess of the maximum speed shown below and further reduction made where conditions require:

	Type of equipment M.P.
	Trains handling ore cars LoadedEmpty
	Trains handling ore loaded in open top equipment other than ore cars
	Trains handling loaded air dumps (must stop when meeting trains on double track)
	Work trains with workmen or occupied outfit cars Scale test cars On Branch Lines On Main Lines
	The following diesel engines either dead in train or operating under own power:
	1670 and 1671, 2000 to 2006 AB
335	610 to 1635
1	600 to 1603

G31 Unless otherwise specified, the speed of all trains or engines approaching interlocked railroad crossings must be reduced, and passenger trains must not exceed 45 miles per hour and other trains or engines 25 miles per hour when passing over such crossing. The stated speed must be further reduced where conditions require. This does not apply to railroad crossings protected by automatic signals or gates; trains and engines will approach such crossings at restricted speed and if proper proceed indication is received, may pass over the crossing at the speed prescribed by Special instructions or bulletin.

1699 to 1709\_\_\_\_

The speed of all trains must not exceed 20 miles per hour while passing over railroad crossings protected by signals or gates unless otherwise specified.

- G32 The speed of trains handled by Gas-Electric or other similar type power, when consisting of power unit only, must not exceed 10 miles per hour when approaching and passing over railroad crossings protected by automatic signals.
- G83 That enginemen may have knowledge of the maximum permissible speed around curves and at points where normal authorized speed must be restricted, a yellow sign with or without the black letters R.S. and black figures and placed at an upward angle of 45 degrees on the right hand side of the track, indicates that the permissible speed beginning 3,000

feet distant corresponds in miles per hour to the figures shown. A yellow sign with the black letters R.S. and placed in a vertical position on the right hand side of the track, indicates that normal speed may be resumed.

These signs do not apply to trains which by timetable or other instructions, are restricted to a slower speed.

Where these signs have two sets of figures, the outside figures apply to the movement of freight trains and those nearest the track apply to passenger trains.

G34 Spring switches:

Movement in facing point direction over a spring switch equipped with facing point lock may be made at normal speed. Movement in facing point direction over a spring switch not equipped with facing point lock must not exceed 25 miles per hour. If switch is lined for turnout, the allowable turnout speed must be observed.

Movement in trailing point direction over a spring switch on track for which the switch is lined may be made at normal speed.

Movement in trailing point direction which springs the switch points must not exceed 40 miles per hour.

If movement is through turnout the allowable turnout speed must be observed.

See Rules 520 to 525 inclusive.

- G34 (A) Spring switch must not be thrown by hand when wheels are standing on any part of the switch points, nor before the points have completed their full movement after being trailed through.
- G35 In addition to Consolidated Code Rule 801 about handling of occupied outfit cars, the following will also apply on this Railroad:

When occupied outfit cars are set on a siding, the switches at each end should be spiked to prevent any possibility of a train striking the cars.

The same principle will also apply when such cars are placed on other side tracks; but when, for operating reasons, it is not practicable to have the switches spiked, the train dispatcher must be notified.

When occupied outfit cars are standing on other than siding and the switches on each end are not spiked, a yellow signal must be displayed on each end of the outfit cars. Under such conditions, the cars must not be moved except when necessary and then only after the man in charge has given his permission. When other cars are placed on the same track, the yellow signal must be moved to the end of the string of cars on that track where it can be plainly seen.

- G36 When a train order office is closed during the period authorized by time-table or bulletin, the light in the train order signal will be extinguished.
- G37 Excessive use of sand at any point is prohibited, and its use must be restricted to actual necessity.
- G38 When passenger trains are unusually delayed, passengers should be informed as to cause and extent of delay.

Conductors will make suitable announcements to passengers on trains or arrange for brakeman and sleeping or parlor car employes to do so.

Agents or station masters will see that such announcements are made to passengers in stations when waiting for delayed trains.

Public address system should be utilized both at stations and on trains when available.

- G39 In complying with Rule 3, of the Consolidated Code of Operating Rules and General Instructions, the prescribed form for Yardmasters and Foremen of Yard Engines to register the time when watches are compared will be the place provided on back of their time slip.
- G41 Where Automatic Block and Interlocking rules and signal indications require movement at RESTRICTED SPEED, such movement must be made prepared to stop short of train, obstruction or switch not properly lined, and be on the lookout for broken rail or anything that may require the speed of a train to be reduced, but a speed of 15 miles per hour must not be exceeded.

G42 When flat spots develop enroute on car or locomotive wheels, speed of train must be reduced to not exceed forty (40) MPH to the first available point of communication, where Conductor or Engineer will notify Chief Dispatcher and be governed by his instructions. If in the judgment of the Conductor or Engineer a lesser speed is deemed advisable, speed of the train will be reduced in line with their judgment.

From tests made it develops that it is desirable, in order to reduce the impact, to operate cars or locomotives with flat spots at a speed either under seventeen (17) MPH or in excess of twenty-three (23) MPH as the most severe impact occurs at speeds seventeen (17) to twenty-three (23) MPH.

G43 A red lantern is not required as part of a flagman's night signals except when operating over a foreign line where the operating rules require its use.

Rule 35 modified accordingly.

All engines in any class of service will be equipped with red lantern in compliance with rule 920 and all cabooses will be equipped with a red lantern to comply with Rule 19 (A) or any other emergency that might require its use.

All other Operating Rules requiring the use of a red lantern remain in effect.

G45 The provisions of Rule 30 of the Manual of Rules and Instructions on Air Brake and Train Air Signals Form 2697 Revised, will apply as follows at the following points:

Aberdeen, Miles City, Deer Lodge, Othello\_\_\_ St. Paul.\_\_\_\_\_\_Freight trains only Minneapolis\_\_\_\_\_\_Passenger trains only

X1 Trains handling steam derricks must not exceed the following speed limitations. The indicated maximum speeds must be further reduced on tangents and on curves where track is not in proper condition for the specified maximum speeds.

	On Tangent Track	
First Subdivision	35 M.P.H.	25 M.P.H.
Second Subdivision	35 M.P.H.	25 M.P.H.
Third Subdivision		20 M.P.H.
Fourth Subdivision		25 M.P.H.
Fifth Subdivision	20 M.P.H.	15 M.P.H.
Sixth Subdivision	20 M.P.H.	15 M.P.H. 15 M.P.H.
Seventh Subdivision	20 M.P.H.	15 M.P.H.
Eighth Subdivision	25 M.P.H.	15 M.P.H.
Ninth Subdivision	20 M.P.H.	10 M.P.H.
Tenth Subdivision	15 M.P.H.	10 M.P.H.
Eleventh Subdivision	25 M.P.H.	20 M.P.H.
Twelfth Subdivision		20 M.P.H.
Thirteenth Subdivision		20 M.P.H.
Fourteenth Subdivision		15 M.P.H.
Fifteenth Subdivision	15 M.P.H.	10 M.P.H.
Sixteenth Subdivision		10 M.P.H.
Seventeenth Subdivision		10 M.P.H.

X2 Trains handling rotary snow plows, locomotive cranes, Jordan spreaders, shovels, pile drivers and ditching machines must not exceed speed limitations shown below. The indicated maximum speeds must be further reduced on tangents and curves where track conditions do not justify the specified maximum speeds. Engine and train crews will make frequent observations of how these machines are riding and when in damaged or questionable condition, or when this equipment is hauled in trains with heavy end trailing, the speed must be further reduced to insure safe movement.

	On Tangent Track	On Curves
First Subdivision	35 M.P.H.	25 M.P.H.
Second Subdivision		25 M.P.H.
Third Subdivision		20 M.P.H.
Fourth Subdivision	35 M.P.H.	25 M.P.H.
Fifth Subdivision		15 M.P.H.
Sixth Subdivision		15 M.P.H.
Seventh Subdivision		15 M.P.H.
Eighth Subdivision	20 M.P.H.	15 M.P.H.
Ninth Subdivision	20 M.P.H.	15 M.P.H.
Tenth Subdivision	15 M.P.H.	10 M.P.H.
Eleventh Subdivision	20 M.P.H.	15 M.P.H.
Twelfth Subdivision		20 M.P.H.
Thirteenth Subdivision	25 M.P.H.	15 M.P.H.
Fourteenth Subdivision		15 M.P.H.

Fifteenth Subdivision	15 M.P.H.	10 M.P.H.
Sixteenth Subdivision	15 M.P.H.	10 M.P.H.
Seventeenth Subdivision	15 M.P.H.	10 M.P.H.

X3 The speed of all trains or engines passing through turnouts must not exceed 13 miles per hour, except those turn-outs laid with long frogs and designated by Special Instructions or bulletin where the speed may be increased to 25 miles per hour, unless otherwise authorized.

Turnouts laid with long frogs are located at:

Turnout from CMStP&P to PCRR track Turnout from CMStP&P to UPRR track Maple Valley Tacoma Jct.

X3 (A) All spring switches except those indicated below are equipped with facing point locks, permitting maximum permissible speed in the territory involved while moving against the points. The speed must not exceed 25 MPH while moving against the points at the following spring switches. (See Special Instruction G34).

Ragnar\_ West siding switch Tacoma Jct.\_\_\_\_\_East End of double track Frederickson\_\_\_\_\_ \_\_Junction switch Maytown. Junction switch

Signals at spring switches at Tacoma Jct., Frederickson and Maytown indicate only the position of the spring switch.

X3 (B) Speedometers on road engines in main line service must be checked by observing time between "Speed Test Section" signs.

Where there are no "Speed Test Section" signs in use, the check must be made between mile posts at first opportunity after departure from point where engineer takes charge of

The location where test was made, speed at time of check

and any variation must be shown on the work report. "Speed Test Section" signs are located as follows:

First Subdivision\_\_\_\_\_Eastbound at MP 1967 and 1970 Second Subdivision\_\_\_\_\_Westbound at MP 1991 and 1994 Fourth Subdivision\_\_\_\_Eastbound at MP 2186 and 2189

- X4 Electric freight engines class EF-1, EF-2, EF-3, and EF-5 must not exceed a speed of 45 MPH.
- X5 Ten-minute fusees should be used on First, Second, Third and Fourth Subdivision. Five-minute fusees should be used on all other Subdivisions except where operating under the rules of another railroad, requiring the use of ten-minute
- X6 When any type of engine is used in helper service on passenger trains, the helper engine should be placed on the head
- X7 Log handling trains will come to a stop while passenger trains are being met or are passing.
- X8 The wires on the trolley and transmission line poles and supports carry high voltage. Contact with them either by person or equipment is liable to cause fatal injury or damage to property. THEY MAY BE HANDLED ONLY BY THOSE WHO HAVE RECEIVED SPECIFIC AUTHORITY TO DO

If wires are found hanging down or any part of the trolley or transmission system deranged in such a way that a person might come in contact with the wires, the train dispatcher must be notified from the first point of communication.

If conditions are such that train or equipment is unable to pass without touching the wires, the train dispatcher must be notified and he will give necessary instructions.

In case of fire, extinguishers filled with carbon tetra-chloride only should be used if it is possible for the extinguishing liquid to come in contact with the wires.

In case of electric shock, resulting in apparent unconsciousness, application of the Back Pressure, Arm Lift Method of resuscitation must proceed immediately; the knowledge of this method is required of all persons having duties within the electrified zone.

Freight trainmen will not be required to ride on top of train in electrified territory unless some real emergency condition exists, which, in the judgment of the conductor of the train, would require special attention from some member of the crew located on top of the car. These instructions are not to be considered as relieving trainmen from the necessity of getting on top of cars while switching operations are carried on when conditions require. However, in no case must trainmen get on top of cars where, on account of lack of clearance, there is danger of contacting any part of energized trolley system.

Due to settling of trolley poles on fills, raising of track when ballast is applied, and other similar causes over a period of years, the height of trolley wire above top of rail is variable; and in some locations, it is less than standard height of 24'2".

X9 At the following stations, the siding is also used as a house track; the train dispatcher need not be notified when cars are left on any of these sidings:

First Subdivision	Ewan
Fifth Subdivision	All Stations
Sixth Subdivision	All Stations
Seventh Subdivision	All Stations
Eighth Subdivision	All Stations
Ninth Subdivision	
Eleventh Subdivision: Allison, Frederickson, Eatonville Jct., Elbe, Mineral, Morton.	Thrift, Tanwax,
Twelfth Subdivision: Greendale, McKenna, Lake, Maytown, Centralia, Chehalis.	Rainier, Offutt
Thirteenth Subdivision	All Stations
Fourteenth Subdivision	

Sixteenth Subdivision\_\_\_\_\_All Stations

X10 Operation of trains on mountain grades.—In addition to instructions contained in Manual of Rules and Instructions on Air Brake and Train Air Signals, Form 2697 Revised effective Jan. 1, 1958 in which reference is made to rules and paragraph numbers, the following will govern:

Seventeenth Subdivision\_\_\_\_\_

Fifteenth Subdivision\_\_\_\_\_

(a) When there is no helper on the rear, the rear car must be one that is equipped with a good hand brake. Conductors are responsible for having trainmen properly stationed.

\_\_\_\_\_All Stations

- (b) When a helper is used on the rear of a freight train, it must be in advance of outfit cars, or cars of insufficient strength to safely resist the push of such helper.
- (c) Before commencing descent of grade from Hillsdale to C Street, Tacoma, a brake pipe test as per Rule 128 must be made and all retainers must be turned up on eastward trains between Hillsdale and Tacoma as per Rule 107.
- (d) Before commencing descent of grade from New Reliance to Eatonville Junction, brake pipe test as per Rule 128 must be made at New Reliance, and retainers must be turned up between New Reliance and Eatonville Junction as per Rule 107. Does not apply to trains handled by diesel electric engines equipped with regenerative braking.
- (e) Before commencing descent of grade from MacPhall to Sutico, a sufficient number of retainers as determined by the conductor and engineer handling the train will be turned up to insure proper control of train speed. When engineer handling train is not familiar with this portion of the railroad, retainers must be turned up on all cars in the train.
- (f) When trains are descending mountain grades and the air brakes are being used, trainmen must watch closely for excessive heating of the wheels and if any are found, the train must be brought to a stop and remain standing a sufficient length of time to permit the wheels to cool.
- (g) Rule 49 (Inoperative Air Brakes) does not apply on mountain grade.
- (h) In electrified territory, the use of retaining valves and

the testing of brakes before starting descent is not required providing there has been no change in position of hose cocks or double heading cocks since last test, EXCEPT when necessary to hold train with air brakes, in which case Rules 107, 129 and 130 will govern.

(i) If regeneration fails while descending mountain grade, the following will apply:

On freight trains, trains must be brought to a stop immediately, all available retainers turned up as outlined in Rule 130 and the brake pipe pressure fully restored before proceeding.

On passenger trains, Rule 107 will apply and retainers will be used only when requested by the engineer.

- (j) Engineers on freight trains must adjust the brake pipe feed valve pressure to 90 lbs, and have brake pipe charged to this pressure before commencing descent of mountain grade as per Rule 129. When there is no stop to be made at summit of mountain grade, engineers will adjust the brake pipe pressure to 90 lbs. four miles before reaching summit and trainmen on rear must note that pressure is being raised as indicated by caboose gauge as per Rule 82.
- (k) Whenever the engine handling a freight train is to be detached on a mountain grade, in addition to the use of hand brakes, the engineer on the helper engine will cut in the brake valve on his engine and keep the brake pipe fully charged. If two helpers are used, the one nearest the head end will cut in the brake valve on his engine. When the road engine is again attached to the train, the helper engineer will cut out the brake valve on his engine. Brake pipe test as per Rule 128 must be made before proceeding.
- (1) All trains descending the grade Boylston to Beverly and Rockdale to Cedar Falls with air brakes only, will stop at Rye and Garcia for inspection and to permit wheels to cool.

When air brakes are used in conjunction with regeneration, stop will not be required, but trainmen and enginemen must be governed by Paragraph (f).

- (m) On descending grade when power goes off the line, train must be immediately brought to a stop. If power does not come on the line again within one minute, engineer will notify trainmen who will immediately set enough hand brakes to alone hold the train. When power again comes on the line, engineer will recharge the brake pipe. Hand brakes must not be released until it is known that the air brake system has been fully recharged and the brakes operative.
- (n) All trains descending grade designated as mountain grade in electrified territory with a power unit that will not regenerate, must, upon request of the engineer, turn up all available retainer valve handles just before passing over the summit of such grades and turn them down when foot of grade has been reached. See Rules 107, 129 and 130.
- (o) With no helper at the rear of the train and a backing movement is made during the ascent of the grade, the brake pipe test as per Rule 128 must be made before the backing movement begins; the brake pipe pressure must be fully restored, a sufficient number of hand brakes applied on the rear of the train to properly control the slack, and a man stationed within reach of the Conductor's valve in order to stop the train promptly in case of emergency. If there is a helper in the train when the backing movement is to be made, the following will govern:

When the engineer on the road engine applies the brakes for brake-pipe test, he will cut out the brake valve on his engine and when the test has been completed, the engineer on the helper engine nearest the

rear end will cut in the brake valve on his engine, fully recharge the brake pipe and control the air brakes during the backing movement; electric locomotives should be operated in series regeneration during the backing movement.

When the backing movement has been completed, the engineer on the helper engine will make a full service application of the train brakes and cut out the brake valve on his engine; the engineer on the road engine will cut in the brake valve on his engine and release the brakes. Trainmen must know that the brakes on the rear end of the train are released before the train starts.

X12 In placing passenger equipment with buffers in freight trains, such cars must not be placed between freight cars equipped with top pin lifter couplers unless the top pin lifter couplers have a direct connected uncoupling rod (not a chain) and provided the coupler heights are such that the buffer will not come in contact with the lock lifter or the uncoupling

Express refrigerators or passenger cars equipped with U. C. brake equipment, when handled in freight trains, should be handled on the head end of the train.

Passenger cars equipped with L. N. brakes can be hauled

in either head or rear end of freight trains.

- X13 When safe operation of trains will permit, brakes should not be applied on engine or cars during dry weather while passing over Bridge EE-384-B, four and one-half miles west of Ellensburg; Bridge EE-386-B, five and one-half miles west of Ellensburg, or other open deck trestles or bridges between Malden and Tacoma.
- X14 At Tacoma Jct., when there are train orders affecting yard movements or westward trains moving to Tide Flats Yard or Tacoma on the Fourth Subdivision, Train Dispatcher will instruct the Operator to stop such movements before making delivery of the train orders.
- X15 Until further notice, all eastward trains handling loaded log cars and all other trains which in the engineers' judgment require increased braking power will raise air brake train line pressure to 100 lbs. at Hillsdale.

Feed valve should be set at normal pressure after arrival

of train at Tide Flats Yard.

X16 Dangerous gases are present in the exhaust from engines of the Waukesha or similar type used for air conditioning and power supply. These gases, if present in sufficient concentration, may cause illness or even fatalities if they are drawn into the cars by circulating fans such as when a train is stalled in a tunnel or in deep snow.

If a train hauled by a diesel engine is stopped in a tunnel under circumstances where it cannot proceed through or back out of the tunnel promptly, the engine crew will immediately shut down the diesel engines and in addition, on passenger trains, the Clarkson or other type steam generators. The train crew of passenger trains will promptly shut down Waukesha or similar type ice engines and engine generator sets only on those of the following cars which are so equipped and which may be standing in the tunnel:

Touralux sleepers Diner P & B Cars Coaches Coaches Super Dome Cars All Business Cars 5752, 5753 and 5754 206 and 207 454 to 478 inclusive 649, 650 and 651 50 to 59 inclusive

(Instructions for shutting off and turning on air conditioning will be found in electrical control locker in each

Circulating fans must be shut down on all cars standing in the tunnel

Use of lights and other electrical equipment must be held to a minimum to prevent excessive discharge of batteries.

Blower fans on all steam jet air conditioned cars standing OUTSIDE the tunnel ONLY, may be used to keep the cars properly ventilated.

If a passenger train is stalled in snow of sufficient depth which will restrict the dissipation of the exhaust gases from Waukesha or similar type engines, such engines must be stopped immediately.

- X17 At Marengo, Maple Valley, Black River and Tacoma Junction, trains other than those displaying signals for a following section, may register by register ticket.
- X18 Seattle water shed extends from one mile east of Cedar Falls station to Landsburg, and from Cedar Falls station to one mile west of station on Eighth Subdivision. All toilets must be kept locked in trains in this district and in city limits Renton and Seattle. Refuse must not be thrown from private, dining, or other cars within these limits. Conductors will be held responsible for strict observance of this rule.
- X19 In addition to those designated in timetable, standard clocks are located in Tide Flats Yard Office, Train Dispatcher's Office, Tacoma Roundhouse Office, Spokane Roundhouse and Telegraph Office.
- X20 Manually controlled crossing signals are in use at D Street, Tacoma. Movement on team track over D Street must be protected by a member of the crew taking a position on the crossing to warn highway traffic of approaching trains.
- X21 In Automatic Block Signal territory, Manual Block System Rules will apply when trains are run against the current of traffic.
- X22 If trolley wires are observed to be slack the pantograph should be lowered and locomotive drifted by. If there is any question about low wires becoming entangled with locomotive or cars, train should be brought to a stop immediately and actual condition with regard to clearance of wires above locomotive and cars should be determined before proceeding.
- X23 Eastward second and inferior class trains and engines and yard movements must not enter upon the eastward main track between Depot Switch and Tacoma Jct. until it has first been determined that all eastward first class trains due at Tacoma Jct. have passed Tacoma Jct. Westward second and inferior class trains and engines and yard movements must not enter upon the westward main track between Tacoma Jct. and Depot Switch until it has first been determined that all westward first class trains due at Tacoma have arrived Tacoma.
- X24 Cle Elum Substation is operated automatically. Emergency switch is located in Cle Elum Depot just west of Operator's desk which may be opened in an emergency, but after doing so, Train Dispatcher must be notified so that proper protection will be provided in addition to flagging air gap.

X25 CREWS HANDLING ELECTRIC ROTARY SNOW PLOWS WILL BE GOVERNED AS FOLLOWS:

- (A) When moving to and from terminals, not in snow operation, pantograph must be locked down and secured to prevent coming in contact with trolley. Grounding switch must be in proper position.
- (B) Must have regular air gap order at all times.
- (C) When handled by diesel power and crew has air gap order, pantograph must be locked down and secured before passing air gap and order issued: "May pass air gap after it is known pantograph is locked down and secured.'
- (D) Crews handling these machines are responsible for knowing pantograph is properly secured and grounding switch is in proper position.

#### FIRST SUBDIVISION

X26 Speed restrictions (In addition to General Speed Restrictions)

	ım Spee Psgr. rains	
Spokane passenger depot, trains handling dome car account depot platforms and girder encasements	10	10
Through City Limits at Malden, Wash	35	35
Through City Limits at Lind, Wash	70	55
Through City Limits at Warden, Wash	50	50
Through City Limits at Othello, Wash	40	40

X27 All trains must approach and leave passenger station at Othello at restricted speed.

X28 When there is a passenger train standing on the main track in the vicinity of the depot at Othello, unnecessary train, switch or engine movements should not be made on the lead track while carmen are between these two tracks watering passenger train.

When such movements are made, extreme caution should be used to avoid injury to these carmen.

X29 At Novara when a westward train is holding main track to meet an eastward train there, it should stop back of battery box 1500 feet west of east siding switch until eastward train approaches.

X30 Rock slide detector fences 657 feet in length located just east of tunnel 44 and 425 feet in length located 800 feet west of west switch Rock Lake siding, are in service.

The signals are of the semaphore type, displaying indications in accordance with Rules 501-A, 501-B and 501-C, Consolidated Code.

For westward trains, if one or both fences have been operated the westward signal located 3293 feet east of tunnel 44 will display approach indication 501-B, and next signal located 1077 feet east of tunnel 44 will display stop indication 501-A.

For eastward trains, if west slide fence is operated eastward signal located 6000 feet west of tunnel 44 will display stop indication 501-A. When fence east of tunnel 44 is operated eastward signal located 6000 feet west of tunnel 44 will display approach indication 501-B and next signal located 360 feet west of tunnel 44 will display stop indication 501-A.

When fences are normal and have not been operated, signals in either direction will display proceed indication 501-C.

These signals are not controlled by track circuit and serve only to check and indicate condition of the slide detector fence.

Trains must be brought to a stop before passing signals displaying a stop indication and proceed at restricted speed through the area protected by a slide fence, making sure that track and bridge structures are in a safe condition.

# SECOND SUBDIVISION

X31 Speed Restrictions (In addition to General Speed Restrictions)

Maximum Spee	d MPH.
Psgr.	Other
Trains	Trains
Bridge EE-260, 31/2 miles west Smyrna 50	40
Bridge EE-384-B, 21/2 miles east Thorp 50	40
Corporate Limits Town of Othello, Wash 40	40
Corporate Limits Town of Kittitas, Wash 65	50
Corporate Limits City of Ellensburg, Wash 50	35
Corporate Limits Town of Cle Elum, Wash. 60	50

#### THIRD SUBDIVISION

X32 Speed Restrictions (In addition to General Speed Restrictions)

Maximum Speed	d MPH.
Psgr.	Other
Trains	Trains
First curve east and first curve west Bridge	
FF-4, 3½ miles west Cle Elum 45	35
Corporate Limits Town of Cle Elum, Wash 60	50

X33 Trains handling logs loaded on flat cars without side stakes should not exceed a speed of 15 M.P.H. when operating over bridge FF-120, one mile west of Cedar Falls Depot.

#### FOURTH SUBDIVISION

X34 Speed Restrictions (In addition to General Speed Restrictions)

Maxin	mum Spe	ed MPH.
	Pagr.	Other
	Trains	Trains
Over N.P. Crossing Black River	35	35
East Leg of Wye Black River	13	13
Corporate Limits Town of Pacific, Wash.	50	50

X35 At Tacoma, the normal position of the crossing gate over the N.P. crossing at Lincoln Avenue east of the roundhouse, is for movements on the CMStP&P tracks.

X36 Manually controlled switches for operating traffic signal lights at the foot of west end of Eleventh Street Bridge Tacoma must be operated when switching movements are made over Eleventh Street.

X37 Manually controlled switches are installed to permit the starting or stopping by hand of crossing signals at Pacific Highway crossing at Sumner.

This switch consists of a knob, with a cover locked with a switch lock, on a box mounted on the instrument case for the crossing signals which is between the main track and siding and just east of the crossing. To operate, unlock cover, turn knob in one direction to stop signals, and opposite direction to start signals.

X38 At Tacoma, before a train or engine enters onto or makes a move over the crossing at Pacific Avenue, South 26th Street and Wakefield Drive, a trainman must first place the City Traffic lights at the crossing in a STOP position by operating switch located in box on either side of crossing.

After movement has been completed, the Traffic lights must be restored to normal position by operating switch located in box on opposite side of crossing.

X39 Union Pacific Class Engines 3800, 3900 and 4500 HP Alco-GE gas turbine electric engines are prohibited from using the following tracks between Black River and Tacoma Jct.:

Sumner: Associated Frozen Foods Track. Track over Stuck River Bridge serving Standard Brands, Fibreboard Products and Pacific Lumber Agency.

In addition to the above restrictions, the maximum speed permissible for this class engine between Tacoma Jct. and Black River is 60 MPH, subject to speed restrictions due to curvature and other time table or special instructions.

D-12	D-45	D-15	D- 3.8
D-16	D-24	D-10	D-48
D-30	D-20	D- 6	D-60
D.40			

Note: The number following the D indicates the horsepower, in hundreds, and includes all engines of that horsepower.

X40 Eastward trains having authority to hold main track when meeting westward trains at Puyallup must not pass signal at west switch until westward train has arrived. A train on main track between switches will give a westward train a stop indication at the west switch at Sumner.

X41 The signal located 850 feet west of Tacoma Jct. office on Fourth Subdivision governs eastward movements from east-

ward track and will display indications in accordance with Rules 601 A Fig. 11 and 601 F Fig. 7. (See Rule 514.)

The eastward signal located 225 feet west of Tacoma Jct. office on Eleventh Subdivision governs eastward movements and will display indications in accordance with Rules 601 A Fig. 8, 601 B Fig. 7, 601 C Fig. 7, (See Rule 519), Rule 601 D Fig. 3.

The three-unit westward signal located 550 feet east of Tacoma Jct. office governs westward movements as follows:

The top unit governs westward C.M.St.P.&P. movements to the Eleventh Subdivision and will display indications in accordance with Rules 601 A Fig. 9 and 601 B Fig. 8.

The middle unit governs westward movements to the U.P. track and will display indications in accordance with Rules 601 A Fig. 9 and 601 E Fig. 8.

The lower unit governs westward C.M.St.P.&P. movements on Fourth Subdivision and will display indications in accordance with Rules 601 A Fig. 9 and 601 F Fig. 5.

The signal located 35 feet east of Tacoma Jct. office on the U.P. track governs movements to C.M.St.P.&P. track and will display indications in accordance with Rules 601 A Fig. 6, 601 B Fig. 5 and 601 C Fig. 5.

X42 All eastward trains from Tacoma Line, will, upon arrival at Black River Yard, register with operator Black River Tower by telephone unless register check has previously been left at Tower.

#### FIFTH SUBDIVISION

X43 Speed Restrictions (In addition to General Speed Restrictions)

1000 H.P., 1200 H.P., GP-9 4-wheel truck 1750 H.P. and SD-7 6-wheel truck 1750 H.P. diesels must not exceed 35 MPH Tiflis to MP 12.8 west of Goodrich and 15 MPH from MP 12.8 to end of line.

At Tiflis, trains and engines must not exceed 10 MPH between the switches on Moses Lake leg of the wye on Fifth Subdivision.

Maximum speed authorized by State of Washington through city limits at:

Moses Lake \_\_\_\_\_\_\_25 M. P. H.

#### SIXTH SUBDIVISION

X44 Speed Restriction (In addition to General Speed Restrictions)

1000 H. P., 1200 H. P. and 1750 H. P., four wheel truck diesel must not exceed 15 M.P.H. between Tiflis and Marcellus.

# SEVENTH SUBDIVISION

X45 Speed Restrictions (In addition to General Speed Restrictions)

Maximum Speed MPH.

#### EIGHTH SUBDIVISION

X46 Speed Restrictions (In addition to General Speed Restrictions)

Maximum Speed MPH. All Trains

All Trains

Monroe to Cedar Falls	
1000 and 1200 HP Diesels	25
1750 HP 4-wheel truck Diesels	15
1.5 miles west Cedar Falls to one-half mile east	
Tanner	.15
Within Yard Limits Snoqualmie Falls	6

Trains handling logs: Over highway crossing at Tanner 2 miles east of Carnation to Carnation	10 15
On Curve just west M.P. 38, about 2 miles east Monroe Jct	25
Over Bridge FF-962 between M.P. 39 and 40, about one-half mile east Monroe Jct	15
Corporate Limits Town of North Bend, Wash	15
Corporate Limits Town of Carnation, Wash	20
Corporate Limits Town of Duvall, Wash	20

X46A Engines when doubleheading must not exceed a speed of 15 miles per hour over bridge FF-856-B one-half mile east of Carnation, and over Bridge FF-962 one-fourth mile east of Monroe Jct.

#### NINTH SUBDIVISION

X47 Speed Restrictions (In addition to General Speed Restrictions)

Maximum Speed MPH.

X48 Between Bayne Jct. and Bagley Jct. via joint track, Northern Pacific wrecking derricks 41 to 48, inclusive, Pile Driver 25, and engines heavier than NP class S-4 not permitted.

Between Bayne Jct. and Enumclaw, Northern Pacific engines, classes A-2 to A-5, inclusive, and Z-5 to Z-8, inclusive, not permitted.

X49 Trains handling logs will not cross on overhead bridge between Bayne Jct. and Kanaskat Jct. while a train is passing under this bridge on Northern Pacific First Subdivision.

X50 At Selleck the Cascade Timber Company's tracks may be used to a point 250 feet beyond the east switch. All movements must be made at restricted speed, looking out for engines and cars of the Cascade Timber Company. Derail is located on west end of Northern Pacific siding and on Cascade Timber Company's track 1000 feet west of west yard switch.

#### **ELEVENTH SUBDIVISION**

X51 Speed Restriction (In addition to General Speed Restrictions)

Maximum Speed MPH.

X52 When shoving cars over highway crossings on Kosmos Logging Line between Morton and Interchange Track, trains must come to a full stop and flag the crossing. During the night the crossing floodlight must be lighted for all trains while passing over crossing.

X53 Eastward trains and engines on Eleventh Subdivision moving between Hillsdale and Tacoma Jct. must stop before passing stop board located just west of C Street.

TWELFTH SUBDIVISION	FIFTEENTH SUBDIVISION
X54 Speed Restrictions (In addition to General Speed Restrictions)	X60 Speed Restrictions (In addition to General Speed Restrictions)
Maximum Speed MPH.  All Trains Over RR Crossings Blakeslee Jct	Maximum Speed MPH.  All Trains  Bellingham to Glacier  1750 HP 4-wheel truck Diesels not permitted.  1000 and 1200 HP Diesels
THIRTEENTH SUBDIVISION  X58 Speed Restrictions (In addition to General Speed Restrictions)	X62 When trains operating on the Fifteenth and Sixteenth Sub- divisions are double-headed, there must be at least 8 cars between engines.
Maximum Speed MPH.  All Trains  Maytown to Helsing Jct.  1000 and 1200 HP Diesels	SEVENTEENTH SUBDIVISION  X63 Speed Restrictions (In addition to General Speed Restrictions)  Maximum Speed MPH.
FOURTEENTH SUBDIVISION  X59 Speed Restrictions (In addition to General Speed Restrictions)  Maximum Speed MPH.  All Trains  Dryad to Raymond	Port Angeles to Discovery Jct.  1750 HP 4-wheel truck Diesels
1750 HP 4-wheel truck Diesels 15	X64 C.M. St. P. & P. Engines are prohibited from using east leg of old wye at Port Townsend.